

## Painting your SlimWall:

We recommend that you use Dulux Weather Shield or a similar self priming premium brand of exterior grade paint. A base primer is not required as long as the paint being applied is self priming and suitable for untreated fibre cement/masonry substrates.

## Surface Preparation



### Posts, Trims and Post Tops

The metal surfaces to be painted must be clean, dry and free of contaminants.

Lightly scuff/rub down all Metal and Primed components with a 3M Scotch Brite pad prior to the application of paint. Scotch Brite pads are available from most paint stores.

NOTE: The light key this gives won't be visible but it is effective!

### Panels

Prepare the surface by ensuring that the Panels are clean, dry and free of contaminants. This can be achieved by means of a brush down with a stiff brush or rubbing lightly with a 'Scotch Brite' pad.

## Application Procedure

### Posts, Trims, Post Tops and Panels

Two coats of paint are required. We recommend applying the first coat with a roller. Cut in the sections that the roller missed with a brush prior to applying the second coat. Let the first 'cutting in' dry and apply a second 'cutting in' coat prior to the second and final roller coat. On a large job a spray application may be justified. Please see the paint manufacturer for advice on spray application.

**We recommend you paint your wall within 90 days of installation**