



Universal Throttle Cable Instruction Sheet

Part# 69-503, 69-504,
69-509, 69-510.

**WARNING: IMPROPER INSTALLATION AND ADJUSTMENT MAY
LEAD TO CATASTROPHIC ENGINE & CAR FAILURE.**

- 1) Install pedal in the desired location.
- 2) Locate the top hole of the pedal and drill corresponding 5/16" hole into the firewall.
- 3) Remove the **Throttle Body Fitting** and **Cable Adjusters**. **Do not remove the ferrule.**
- 4) Remove the inner cable and put aside. Insert engine side of the cable into the bracket. (Bracket R6055 may be required)
- 5) Remove the **Mounting Nut** from the pedal side of the cable and place into the hole in the firewall from the engine side. Replace **Mounting Nut** and tighten.
- 6) Reinstall cable from inside the vehicle. Connect the **Clevis** to the pedal.
- 7) Reinstall the **Cable Adjusters** and **Throttle Body Fitting**. Pull the slack out of the cable tighten the set screw. Fully actuate the carburetor and pedal. Check for stickiness and any tightness.

