



Wall Mounted Bottle Opener Installation Instructions

Installation - Adhesive mount

The adhesive strips are suitable for painted walls, smooth surface wood, smooth metal surfaces (such as a stainless steel fridge). Many other smooth surfaces should work. If unsure, please test it first.

Exposed brick or rendered concrete walls are not suitable for these poster strips. Also, high heat and humidity areas will not work well.

- Make the poster strips into pairs, by separating them and pushing the velcro sides together tightly.
- Remove the paper from one side and place the poster strips on the back of the bottle opener. Put one on the left of the screws, one on the right, and two vertically above the screws.
- Clean and dry the location where the poster strips are to go.
- Remove the paper from the other side of the poster strips.
- Place the bottle opener against the surface. Hold it in place for 30 seconds with even force to allow the adhesive to bond.

Installation - Screw mount

For brick walls, or high heat or humidity areas, screw mounting is recommended. We do not recommend screwing this to a fridge.

We don't include wall plugs as walls vary greatly. However, we have included suitable screws for wall plugs.

- Remove the existing screws from the bottle opener, and also the plastic nuts embedded into the wood.
- Using the bottle opener, mark where the holes need to go onto the wall with the existing holes.
- Drill and fit wall plugs or similar as appropriate for the surface.
- Using the supplied long screws, go through the bottle opener, the wood backing, and into the holes you have made. There will be some wiggle room to adjust all the components.

Issues or Questions?

If you have any issues at all, please email us at hello@footeandflame.com.au and we'll fix it for you!