

# HOLLAND CONSOLE

DESIGNED BY METRICA

ASSEMBLY INSTRUCTION



## HOLLAND CONSOLE

---

### PACKAGING: CONSOLE WITH WOODEN TOP

- HARD CARDBOARD BOX WITH POLYSTYRENE ON ALL SIDES: WOODEN TOP WITH CABLE MANAGEMENT HOLE PROTECTED BY BLUE MATERIAL
- EXTRA HARD CARDBOARD BOX WITH ASSEMBLED METAL BASE AND A BAG WITH 8 FELT GLIDERS, 6 SCREWS, 6 WASHERS, 1 ALLEN KEY
- OPTIONAL: CARDBOARD BOX WITH 4 CONTRASTING FEET IN A PROTECTIVE BAG

### PACKAGING: CONSOLE WITH MARBLE TOP

- WOODEN CRATE WITH 1 MARBLE TOP AND POLYSTYRENE ON ALL SIDES, 6 SHORT SCREWS AND 6 THICK WASHERS ALREADY INSERTED IN TOP, 1 ALLEN KEY
  - EXTRA HARD CARDBOARD BOX WITH ASSEMBLED METAL BASE AND A BAG WITH 8 FELT GLIDERS, 6 SCREWS, 6 WASHERS, 1 ALLEN KEY
  - OPTIONAL: CARDBOARD BOX WITH 4 CONTRASTING FEET IN A PROTECTIVE BAG
- 

### IMPORTANT NOTE

- ENSURE THAT ALL STEPS ARE FOLLOWED IN THE CORRECT ORDER AND THAT NO STEP IS LEFT OUT.
  - A MINIMUM OF TWO PEOPLE ARE REQUIRED FOR ASSEMBLY.
  - TO PREVENT ANY DAMAGE OF THE PRODUCT, DO NOT USE A CUTTER KNIFE/ SHARP OBJECT TO OPEN THE BOXES.
  - IF YOU HAVE ANY OPTIONAL, READ THE INSTRUCTION FOR YOUR OPTIONAL FIRST.
- 

### ASSEMBLY INSTRUCTIONS: CONSOLE WITH WOODEN TOP

1. REMOVE THE BASE FROM ITS PACKAGING
2. ENSURE THAT THE ADJUSTABLE FEET ARE NOT TOO TIGHT
3. POSITION THE FELT GLIDERS AS SHOWN IN THE DESIGN, MAKING SURE THAT THE GLIDERS DO NOT COVER ANY HOLE
4. REMOVE THE WOODEN TOP FROM ITS PACKAGING AND LAY IT ON A BLANKET/ SOFT AND CLEAN SURFACE WHICH WILL NOT SCRATCH THE SURFACE WITH THE UNDERSIDE FACING UP
5. PLACE THE METAL BASE ONTO THE TOP MAKING SURE THAT THE FOOTREST TUBE IS FACING OUT
6. NOW INSERT THE SCREWS AND WASHERS FIXING THE STRUCTURE ONTO THE TOP USING THE PROVIDED ALLEN KEY
7. TIGHTEN ALL THE SCREWS AND PLACE THE CONSOLE ON ITS LEGS

HOLLAND CONSOLE

---

ASSEMBLY INSTRUCTIONS: CONSOLE WITH MARBLE TOP

1. REMOVE THE BASE FROM ITS PACKAGING
2. ENSURE THAT THE ADJUSTABLE FEET ARE NOT TOO TIGHT
3. POSITION THE FELT GLIDERS AS SHOWN IN THE DESIGN, MAKING SURE THAT THE GLIDERS DO NOT COVER ANY HOLE
4. REMOVE THE MARBLE TOP FROM ITS PACKAGING AND LAY IT ON A BLANKET/ SOFT AND CLEAN SURFACE WHICH WILL NOT SCRATCH THE SURFACE WITH THE UNDERSIDE FACING UP
5. REMOVE THE SCREWS AND WASHERS ALREADY INSERTED INTO THE TOP
6. PLACE THE METAL BASE ONTO THE TOP MAKING SURE THAT THE FOOTREST TUBE IS FACING OUT
7. NOW INSERT THE SCREWS AND WASHERS FIXING THE STRUCTURE ONTO THE TOP USING THE PROVIDED ALLEN KEY
8. TIGHTEN ALL THE SCREWS AND PLACE THE CONSOLE ON ITS LEGS