

LING

DESIGNED BY METRICA

ASSEMBLY INSTRUCTION



LING SOFA + ARMCHAIR

PACKAGING

- CARDBOARD BOX WITH 1 ARMCHAIR/SOFA STRUCTURE IN A PROTECTIVE BAG; 3RD LEG PROTECTED AND LOCKED BY TWO BLOCKS OF FOAM, ADDITIONAL FOAM ANGLES ON TOP OF THE PROTECTING BACK COVERING THE CORNERS OF THE WOODEN STRUCTURE; FEET FELT PADS ALREADY ATTACHED
 - ARMCHAIR VERSION: CARDBOARD BOX AND A THIN PROTECTIVE BAG:
1 SEAT CUSHION, 1 BACKREST CUSHION, 1 BACKREST PANEL WITH 2 PINS, 2 SCREWS AND 1 ALLEN KEY, 2 SCREWS, 2 WASHERS, 1 ALLEN KEY
OR
 - SOFA VERSION: CARDBOARD BOX AND A THIN PROTECTIVE BAG:
2 SEAT CUSHIONS, 2 BACKREST CUSHIONS, 2 BACKREST PANELS WITH 4 PINS, 4 SCREWS AND 1 ALLEN KEY, 4 SCREWS, 4 WASHERS AND 1 ALLEN KEY
-

IMPORTANT NOTE

- ENSURE THAT ALL STEPS ARE FOLLOWED IN THE CORRECT ORDER AND THAT NO STEP IS LEFT OUT.
 - A MINIMUM OF TWO PEOPLE ARE REQUIRED FOR ASSEMBLY.
 - TO PREVENT ANY DAMAGE OF THE PRODUCT, DO NOT USE A CUTTER KNIFE/ SHARP OBJECT TO OPEN THE BOXES.
-

ASSEMBLY INSTRUCTIONS

1. REMOVE THE WOODEN FRAME FROM THE PACKAGING AND PLACE IT WITH ITS LEGS ONTO THE FLOOR
2. REMOVE THE UPHOLSTERY AND THE HARDWARE FROM ITS PACKAGING, PLACING IT ON A CLEAN SURFACE/BLANKET
3. TAKE THE UPHOLSTERED BACKREST PANELS WHICH WILL BE FIXED ONTO THE STRUCTURE BY USING THE HARDWARE WHICH IS FIXED ONTO THE PANEL (THE SCREW FOR FIXING THE BAG ONTO THE PANEL IS NOT REQUIRED FOR ASSEMBLY)
4. SCREW THE PIN ONTO THE PANEL ENLARGING THE FABRIC HOLES; THE HOLE IN THE PIN MUST BE POSITIONED VERTICALLY, OTHERWISE IT WILL NOT ENTER INTO THE WOODEN FRAME
5. PLACE THE PANEL ON THE BACK INSERTING THE PINS INTO THE WOOD STRUCTURE
6. MOUNT THE SECURITY SCREWS (SCREWS WITHOUT HEAD) WITHOUT TIGHTENING
7. MOUNT THE SCREWS WITH THE WASHER IN THE LOWER PART OF THE PANEL
8. TIGHTEN ALL THE SCREWS WITHOUT USING FORCE
9. FIRST PUT THE SEAT CUSHION WITH THE ZIPPER ON THE BACK ONTO THE FRAME, THEN PLACE THE BACKREST CUSHION