




ASSEMBLY INSTRUCTION

SMPIPERDWE

PIPER SINGLE DRAWER DESK




Important
Estimated Assemble time: 15min



1 PERSON IS REQUIRED
TO SAFELY ASSEMBLE
THE ITEM




HOTLINE



ASSEMBLE ON A CLEAN,
FLAT SURFACE

Tools Required For Assembly



Please check you have all hardware components before assembling.

If you are missing any hardware components from the Hardware List please contact My Zone on


Tel: (03) 9310 3011, or Email: hardware@myzone.net.au

Please ensure you have the name of the item, store purchased from, hardware part required and quantity.

If you are missing any panels from the Panel List please contact your store of purchase.


Please retain your receipt to validate warranty. Enjoy your new purchase!

Panel List




Hardware List

A




8 pcs

B




M8 X 50mm
8 pcs

C




1 pc

D



4 pcs

E





1 pc

F





Ø3 X 10mm
2 pcs



Step 1



Step 2




Step 3



Maximum Load Capacity:

Desk Top-40kg

Drawer-5kg



**Your PIPER SINGLE DRAWER DESK
is now complete and ready for use.**

Officeworks Superstores Pty Ltd.|236-262 East Boundary Road|East Bentleigh|3165|AUSTRALIA