

## Attaching the FUSION Puck™ Mount

The Puck allows you to quickly and securely fit a **STEREOACTIVE** or **ACTIVESAFE** to the surface of a paddle board, kayak, canoe, dinghy/tinny/jon boat, jacuzzi and any flat surface.

Engineered for easy puck and play placement. The standard Puck solution includes both an adhesive pad and mounting screws for fixed placement.

FUSION recommends fitting the puck cover when the puck is not in use.

For detailed installation instructions refer to the **STEREOACTIVE** owners manual, downloadable from [www.stereoactive.com](http://www.stereoactive.com)

- Before placing the adhesive on the mounting surface, make sure that the location and orientation are correct. It is extremely difficult to remove the adhesive.
- The adhesive and puck mount cannot be reused after being removed from a surface. Some mounting surfaces might be damaged after removing the adhesive.
- Before screwing into the surface, check with the manufacturer of the item on which you are mounting the puck to verify that screws should be used. Some surfaces are too thin to support screws, and the adhesive should be used on these surfaces.
- If these mounting options are not sufficient for your mounting surface, go to [www.stereoactive.com](http://www.stereoactive.com) for more mounting accessories.