

SP01

OUTDOOR

CARE INSTRUCTIONS





THANK YOU FOR YOUR PURCHASE OF AN SPØ1 PRODUCT.

SPØ1 OFFERS AN INTERNATIONAL COLLECTION BUILT ON THE PRINCIPLES OF DESIGN INTEGRITY AND AUTHENTICITY.

WORKING WITH NATURAL MATERIALS OF THE HIGHEST QUALITY, THE SPØ1 COLLECTION OFFERS TIMELESS, SIMPLE AND CONTEMPORARY PRODUCTS MANUFACTURED IN ITALY BY THE WORLD'S MOST EXPERIENCED AND SKILLED CRAFTSMEN.

PLEASE FIND ENCLOSED CARE INSTRUCTIONS FOR YOUR PRODUCT. SPØ1 PRODUCTS ARE DESIGNED AND BUILT TO LAST A LIFETIME, SO PLEASE TAKE CARE OF YOUR PURCHASE AND TREAT THEM WITH CARE.

IF YOU HAVE ANY QUERIES PLEASE CONTACT YOUR CLOSEST SPØ1 SALES CONSULTANT OR VISIT US ONLINE.

ENJOY

OUTDOOR COLLECTION
CARE INSTRUCTIONS FOR REGULAR MAINTENANCE

IMPORTANT NOTE

- SPECIAL ATTENTION AND REGULAR MAINTENANCE IS REQUIRED WHEN LIVING IN COASTAL AREAS.
 - AS EXPOSURE TO SEA AIR ENVIRONMENT MAY ACCELERATE DETERIORATION TO A PRODUCT'S FINISH, REGULAR CLEANING OF INDOOR AND OUTDOOR FURNITURE IS HIGHLY RECOMMENDED.
 - PROTECT FROM RAIN AND DIRECT SUNLIGHT. WHEN NOT IN USE, OUTDOOR FURNITURE SHOULD BE CLEANED, COVERED AND STORED OUT OF THE ELEMENTS.
-

WOOD FINISHES

- TO ENSURE THE GREATEST POSSIBLE ENJOYMENT FROM YOUR FURNITURE AND THE LONGEST LIFESPAN, IT IS IMPORTANT THAT IT IS PROPERLY LOOKED AFTER. WHEN WOOD FURNITURE IS CORRECTLY MAINTAINED AND EXPOSED TO DAYLIGHT, OVER THE YEARS THE WOOD WILL ACQUIRE A BEAUTIFUL PATINA.
- AS WOOD IS A LIVING NATURAL PRODUCT, COLOUR VARIATIONS AND KNOTS AS WELL AS LINES IN THE FINISHED FURNITURE MAY OCCUR.
- WOOD IS A LIVING MATERIAL THAT IS AFFECTED BY DAYLIGHT, TEMPERATURE AND HUMIDITY. THE IDEAL RELATIVE HUMIDITY FOR SOLID WOOD TABLES IS BETWEEN 30% AND 60%. WOOD FURNITURE SHOULD THEREFORE NOT BE PLACED TOO CLOSE TO HEAT SOURCES SUCH AS WOOD-BURNING STOVES OR RADIATORS.
- WOOD TABLE TOPS ARE ALSO AFFECTED AND DRIED BY DIRECT SUNLIGHT. BOTH FACTORS CONTRIBUTE TO VERY LOW RELATIVE HUMIDITY WHICH MAY CAUSE CRACKS IN THE TABLE TOP AND SHOULD THEREFORE BE AVOIDED.
- AS DAYLIGHT MATURES THE WOOD, IT IS ALSO IMPORTANT TO BE CAREFUL WHEN PLACING PERMANENT ITEMS ON A NEW SOLID WOOD TABLE TOP, FOR EXAMPLE DISHES, VASES AND CANDLESTICKS, AS IT CAN CAUSE UNDESIRABLE COLOUR DIFFERENCES AS THE WOOD MATURES WHICH WILL SUBSEQUENTLY BE DIFFICULT TO REMOVE.
- FOR EVERYDAY CLEANING, WIPE THE TABLE TOP WITH A SOFT CLOTH WRUNG OUT WITH CLEAN LUKEWARM WATER.
- AS THE LACQUER SEALS THE SURFACE OF THE WOOD, THE FURNITURE WILL NOT BE AFFECTED BY DAYLIGHT IN THE SAME WAY AS SOAP OR OIL-TREATED FURNITURE. HOWEVER, THE FURNITURE WILL STILL DARKEN WITH TIME, AND WE RECOMMEND THAT YOU EXERCISE CARE WHEN POSITIONING DISHES, CANDLESTICKS, ETC. ON THE SURFACE.
- WE ADVISE AGAINST THE USE OF CLEANING AGENTS OR OTHER FORMS OF CHEMICALS.

OUTDOOR COLLECTION
CARE INSTRUCTIONS FOR REGULAR MAINTENANCE

METAL SURFACES

- REGULAR MAINTENANCE KEEPS METAL FURNITURE AWAY FROM THE DANGER OF RUSTING. WIPE EVERY PART WITH A CLEAN DRY CLOTH REGULARLY.
 - DETERGENTS FOR DELICATE SURFACES ARE RECOMMENDED TO BE USED. ABRASIVE DETERGENTS CONTAINING ALCOHOL, SILICONE OR SOLVENTS ARE TO BE AVOIDED. FINISHED METALS MUST BE CLEANED WEEKLY AND WE SUGGEST WIPING THE SURFACE WITH A VERY LIGHTLY DAMP CLEAN SOFT CLOTH AND DRYING WITH A CLEAN MICROFIBRE CLOTH.
 - NOT EVERY RED SPOT IS NECESSARILY RUST; EVEN THOUGH WHEN RUST HAS STARTED TO BUILD, YOU SHOULD TAKE ALL MEASURE TO CLEAN IT AWAY AND PREVENT IT FROM SPREADING: WASH YOUR FURNITURE REGULARLY WITH SOAP OR MILD DETERGENT AND WARM WATER. SPONGE, RINSE WITH CLEAN WATER AND WIPE DRY.
 - FOR BEST PROTECTION, PERFORM THIS MAINTENANCE TWO OR THREE TIMES PER YEAR IN LOW POLLUTION AREAS OR MORE FREQUENTLY IN HIGH POLLUTION AREAS. PLEASE NOTE THAT THESE DURABLE MATERIALS CAN BE SAFELY CLEANED AS OFTEN AS DESIRED.
 - CAUTION:
WHEN HANDLING PRODUCTS CONTAINING HAZARDOUS SOLVENTS, THE FOLLOWING PRECAUTIONS MUST BE TAKEN: PLASTIC GLOVES AND GLASSES MUST BE WORN; KEEP WINDOWS OPEN AND AERATE THE ROOM: OPERATE AWAY FROM HEAT SOURCES.
-

MARBLE

- EVEN THOUGH OUR MARBLE TOPS ARE SEALED BY PROTECTIVE WAXES, IT IS IMPORTANT TO BE AWARE THAT THOSE TREATMENTS AND WAXES DO NOT SEAL COMPLETELY THE SURFACE, BUT RATHER SLOW DOWN THE ABSORPTION. THEREFORE IT IS NECESSARY TO CLEAN THE SURFACE IN THE SHORTEST POSSIBLE TIME. IT IS RECOMMENDED TO WIPE THE TABLE AFTER EVERY USE.
- REGULAR MAINTENANCE SHOULD BE PERFORMED USING A CLOTH DAMPENED WITH LUKEWARM WATER. IF NECESSARY, A NEUTRAL AND SOFT DETERGENT CAN BE USED.
- IN THE EVENT OF MARKS CAUSED BY LIQUID AND/OR GREASY SUBSTANCES, THE DIRT MUST BE REMOVED IMMEDIATELY USING AN ABSORBENT CLOTH. THE WHOLE SURFACE SHOULD THEN BE WIPED OVER WITH A CLOTH DAMPENED WITH LUKEWARM WATER.
- DO NOT SPILL CHEMICAL SUBSTANCES AND SOLVENTS ON THE SURFACE AS THIS WILL PERMANENTLY MARK THE STONE. KEEP AWAY NAIL POLISH REMOVER, PRODUCTS CONTAINING AMMONIA, BLEACHES, INDELIBLE MARKERS OR INK, OILY SOAPS, LEMON, WINE, COFFEE AND DRINKS THAT CAN STAGNATE AND CORRODE THE SURFACE.
- IF ANY OF THE ABOVE MENTIONED SUBSTANCES COMES IN CONTACT WITH THE MARBLE, WIPE IMMEDIATELY AND RINSE ABUNDANTLY.
- DO NOT USE SOLVENTS, SILICONE AND ABRASIVE DETERGENTS.
- IT IS SUGGESTED TO REGULARLY SEAL THE MARBLE WITH A SUITABLE PRODUCT (E.G FABER HIDRO 150). PRODUCT SHOULD BE APPLIED AS SUGGESTED BY PRODUCER.

OUTDOOR COLLECTION
CARE INSTRUCTIONS FOR REGULAR MAINTENANCE

HPL FINISHES

- HPL DOES NOT REQUIRE PARTICULAR MAINTENANCE THAT GOES BEYOND NORMAL CLEANING. THE COMPACT AND NON-POROUS SURFACE OF THE HPL CAN EASILY BE CLEANED WITH HOT WATER, STEAM, AND ALL TYPES OF COMMON DETERGENTS AND DISINFECTANTS FOR DOMESTIC USE, AS LONG AS THEY ARE NOT ALKALINE. THE HPL IS ANTI-STATIC; THEREFORE, IT DOES NOT ATTRACT DUST. THUS, IT DOES NOT REQUIRE ANY TREATMENTS WITH WAX OR WAX-BASED PRODUCTS: RATHER, THESE PRODUCTS TEND TO FORM A STICKY LAYER ON THEIR SURFACE WHICH RETAINS DIRT.
- CRANBERRY OR BEET JUICE, CONCENTRATED FRUIT OR TOMATO JUICE, CARAMEL AND SOME BLEACH MUST BE REMOVED AS QUICKLY AS POSSIBLE FROM THE HPL SURFACE.
 CAUTION:
- WHEN HANDLING PRODUCTS CONTAINING HAZARDOUS SOLVENTS, THE FOLLOWING PRECAUTIONS MUST BE TAKEN: PLASTIC GLOVES AND GLASSES MUST BE WORN; KEEP WINDOWS OPEN AND AERATE THE ROOM: OPERATE AWAY FROM HEAT SOURCES.

ORIGIN OF DIRT

RECOMMENDED CLEANING PRODUCT AND METHOD

SYRUP - FRUIT JUICE - JAM - LIQUOR - MILK - TEA - COFFEE - WINE - SOAP - INK

WATER AND SOFT SPONGE

ANIMAL AND VEGETAL FAT - SAUCE - DRY BLOOD - DRIED WINE AND LIQUORS - EGGS

COLD WATER AND SOAP OR DOMESTIC DETERGENT. RINSE WELL AND DRY WITH A COTTON CLOTH.

SMOKE-BLACK - JELLY - VEGETAL AND VINYL ADHESIVES - WATER-COLOUR PAINTS - ORGANIC RESIDUES - ARABIC GUM

WASH WITH HOT WATER AND SOAP OR A DOMESTIC DETERGENT. RINSE WELL AND DRY WITH A COTTON CLOTH.

HAIR SPRAYS - VEGETAL OILS - CASTOR OIL - PEN - MARKERS - WAX - FOUNDATION AND GREASY FACE POWDERS - SOLVENT RESIDUE HALOES

MEK - ALCOHOL - ACETONE WITH A COTTON CLOTH. RINSE WELL WITH COLD WATER AND DRY WITH A CLEAN COTTON CLOTH, BLOTTING PAPER OR KITCHEN PAPER.

NAIL POLISH - POLISH SPRINKLES - LINSEED OIL

ACETONE WITH A COTTON CLOTH

NEOPRENE ADHESIVES

TRICHLOROETHANE WITH A COTTON CLOTH

SYNTHETIC OIL PAINTS

TRICHLOROETHYLENE NITRO SOLVENT WITH A COTTON CLOTH

SPRAY PAINTS

THINNER 3M - VANDAL WITH A COTTON CLOTH

ADHESIVES RESIDUES (ACRYLIC OR VEGETAL RUBBER) AFTER REMOVAL OF PROTECTIVE FILM

THINNER 3M - VANDAL WITH A COTTON CLOTH

PAINTS

THINNER 3M - VANDAL WITH A COTTON CLOTH

SILICONE TRACES OR RESIDUES

IF IT IS COMPLETELY DRY IT IS IMPOSSIBLE TO REMOVE. IF NOT, USE VERY GENTLY A WOODEN OR PLASTIC SCRAPER

LIMESCALE

DETERGENTS WITH A VERY LOW PERCENTAGE OF CITRIC OR ACTETIC ACID (MAX. 10%)

OUTDOOR COLLECTION
CARE INSTRUCTIONS FOR REGULAR MAINTENANCE

OUTDOOR SEAT PAD

- USE THE VACUUM CLEANER WITH SMOOTH SPOUT REGULARLY, DON'T BRUSH.
 - FOR HEAVY STAINS USE A MILD DETERGENT AND A SOFT CLOTH.
 - PLEASE NOTE THAT THE SOFT PAD HAS A SPECIAL TREATMENT TO GUARANTEE ITS WATER RESISTANCE, PUTTING THE SEAT PAD INTO THE WASHING MACHINE MIGHT WASH AWAY ITS WATERPROOF QUALITIES.
-

OUTDOOR SOFT CUSHIONS UPHOLSTERY

- USE THE VACUUM CLEANER WITH SMOOTH SPOUT REGULARLY, DON'T BRUSH.
 - FOR STAINS USE A MILD DETERGENT, WATER AND A SOFT CLOTH.
 - IF NECESSARY, THE FABRIC COVERS CAN BE WASHED IN THE WASHING MACHINE AT 40* USING A MILD DETERGENT.
 - DRY CLEANING IS NOT RECOMMENDED.
 - THE FABRIC COVERS MUST NOT BE IRONED.
-

CUSHION INSERTS

- IN ORDER TO BE PROPERLY MAINTAINED, CUSHIONS SHOULD BE PLUMPED UP AND AIRED FREQUENTLY.
- WHERE POSSIBLE, ALTERNATE THE POSITION OF THE CUSHIONS, SWAPPING THE MOST USED CUSHIONS WITH THE LESSER USED ONES.
- TO REJUVENATE, REMOVE THE CUSHIONS FROM THEIR COVERS AND LEAVE THEM OUTDOORS IN DIRECT SUNLIGHT FOR A PERIOD OF TWO HOURS.