


J.BURROWS

• • • • •

ASSEMBLY INSTRUCTIONS

BOSTON LARGE HUTCH DESK BOSTONHUKT



This design and instruction booklet is subject to copyright.

www.officeworks.com.au

3CTNS

For spare parts or hardware call 1300 OFFICE(1300 633 423)

Estimated Assembly Time: 60 minutes

Customer Service Contact Details




Spare Parts & Hardware
1300 OFFICE (1300 633 423)


People Required



General Advice



Tools Required



CAUTION: Do not use tools other than those required, as this can damage your new item.

NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact 1300 OFFICE(1300 633 423)
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION

- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all bolts and screws are firmly secured.
- Check that all bolts and screws are securely tightened at least every 4 months.


WARNING

- If parts are missing, broken, damaged or worn, stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.


DANGER

- CHILDREN MUST BE SUPERVISED.


Parts located in Carton - BOSTONHUC1









Parts located in Carton - BOSTONHUC2



Parts located in Carton - BOSTONHUC3



Hardware Spare Parts number - HWBOSTON

<p>A</p>  <p>32mm x40Pcs</p>	<p>B</p>  <p>∅ 15mm x48Pcs</p>	<p>C</p>  <p>∅ 8x30mm x27Pcs</p>
<p>D</p>  <p>x48Pcs</p>	<p>E</p>  <p>M6*40mm x4Pcs</p>	<p>F</p>  <p>83mm x4Pcs</p>

Hardware located in Carton - BOSTONHUC3

G





Diagram G shows a perspective view of a pre-assembled L-shaped bracket. Two screws are shown above the bracket, indicating they are used to secure it.


pre-assembled


x3Pcs


Assembly

Step 1

A

32mm x2pcs

C

∅ 8x30mm x2pcs



G

pre-assembled
x3pcs





1

5/17


Step 2




Step 3




Step 4




Step 5



Step 6




Left



Detail #B

right




Detail #B


To remove drawer, pull drawer out until stopped, then simultaneously push the left plastic release lever up while pushing the right lever down, then pull the drawer out, as shown.

Step 7


- B




Ø 15mm x4pcs
- D




x4pcs
- E





x4pcs M6*40mm





Step 8








To insert drawer, fully extend both ball bearing tracks on each side and align the slide runners on the drawer with the tracks on the unit. Push the drawer into place until closed. If the drawer does not smoothly push into place, please remove and repeat insertion procedure.



Step 9





Step 10





Step 11





Step 12





Step 13





Step 14





Step 15






Step 16






Step 17




Step 18



Step 19



MAXIMUM WEIGHT CAPACITY



NOTE: Desktop 100kg , shelf 15kg , stationery drawer weight capacity 10kg , filing drawer capacity 30kg



CAUTION: This product is intended to hold the maximum weight indicated. Exceeding the maximum weight will result in instability and may cause injury.

Warranty 8 years

Product Warranty – valid for Australian customers only

Officeworks Ltd warrants that this product will be free from defects and work as intended for 8 years from the date of purchase by the original customer.

If the product has any defects or does not work as intended during the Warranty Period, Officeworks will, at its election and at its expense, repair or replace the product.

This warranty does not apply:

- To cosmetic damage;
- To damage caused by consumables used in connection with the product (such as cleaning products);
- Where the product has not been used in accordance with all provided instructions;
- To damage arising from fair wear and tear;
- Where the product has not been subject to reasonable use;
- Where the product has been intentionally or negligently damaged; and/or if the customer has attempted to repair the product.

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

This warranty is provided in addition to any rights you may be entitled to under the Competitions & Consumer Act 2010.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Thank you for your purchase. Please retain your receipt to validate warranty. If you would like to know more about our furniture products, please visit www.officeworks.com.au