

Instruction Manual

J.BURROWS

.....

Replacement Blade (JBTRMHEAD)

For JBTR410 & JBTR310 Trimmer

Instruction on how to change the blade.

- Detach the clip from one end of the trimmer, which is indicated by the arrow pointing upwards. <Figure 1>



Figure 1

- Slide the metal bar forward through the slot where you have just removed the clip, until the other end of bar comes out. <Figure 2>




Figure 2

- Remove the old blade from the bar and install a new one. When putting in the new blade, make sure that the side with the black rubber pad inside the blade is on the same side as the clear cutting ruler. <Figure 3 & Figure 4>




Figure 3




Figure 4

- To reassemble, first slide the metal bar through the hole, then push the other end of the bar back into its original position. Finally, reattach the clip. Your trimmer is now ready for use again. <Figure 5>




Figure 5

CAUTION: Do not touch the edge of the blade; it's extremely sharp.