



ASSEMBLY INSTRUCTIONS

KIDS PLAY CHAIR WHITE / PINK / BLUE

ITEM# SMKIDPLAYW
SMKIDPLAYP
SMKIDPLAYB



Tools Required



Assemble Item On a Clean Flat Surface





Assembly Time






15 Min


- Please check you have all hardware before assembling.
- If you think you are missing any hardware please contact the store of purchase.
- Please ensure you have the name of the item and hardware part required and quantity.
- Please retain your receipt for proof of purchase to validate warranty. Enjoy your new purchase.

PARTS LIST




HARDWARE LIST








A X1




B X1



X4




X4




Large Allen Key

X1



X4

MAXIMUM WEIGHT CAPACITY



! CAUTION: This product is intended to hold the Maximum Weight indicated. Exceeding the Maximum Weight will result in instability and may cause possible injury.

WARNING

- Do not stand on this chair. Do not use this chair as step ladder.
- Use this product only for seating one person at a time.
- Do not use this chair unless all bolts, screws and knobs are firmly secured.
- At least every 4 months, check all bolts, screws and knobs to be sure they are tight.
- If parts are missing, broken, damaged or worn, stop use of the product until repairs are made, using factory authorized parts.
- Failure to follow these warnings could result in serious injury.

Thank you for purchasing our product! Please retain your receipt to validate warranty