

User Manual

Universal Air Conditioner Remote

LURC041


OFFICEWORKS LTD

User's instruction for all-purpose air conditioner remote control

/ Product Introduction

The Universal Air Conditioner Remote Control is designed to operate a wide range of air conditioner brands and models. It features point-to-point fast brand setting, intuitive operation, and a sleek, modern design that offers a comfortable grip and a pleasant user experience. Equipped with an LCD screen, this remote ensures easy viewing and effortless control, making air conditioner management more convenient than ever.

/ Panel Description:



1. Run Mode Display
2. Fan Display
3. Blowing Direction Display
4. Backlight
5. Temperature Up Key
6. Mode Key
7. Automatic Blowing Direction Key
8. Blowing Direction Control Key
9. Timing OFF Key
10. Timing ON Key
11. Set Key
12. Clock Function Key
13. Model Code
14. Temperature Display
15. Power Key
16. Fan KEY
17. Temperature Down Key
18. Fast Cool Key
19. Fast Heat Key
20. Confirmation Button

/ Remarks

- Press the "Fast Cool" button to automatically set the air conditioner to **cooling mode** at 21°C.
- Press the "Fast Heat" button to automatically set the air conditioner to **heating mode** at 27°C.

/ Battery installation


1. Remove the battery cover from the remote control.
2. Insert **two AAA batteries** into the compartment, ensuring correct polarity.
3. Reattach the battery cover.




/ Setup of Remote Control

This remote control supports three setup modes:

A. Point-to-Point Fast Brand Search














Power on the air conditioner manually. Aim the remote control at the air conditioner's receiver window



Press and hold the brand-specific code key until the air conditioner responds with a sound signal. Release the key once the air conditioner starts. The setup is complete.


Refer to the Brand Corresponding Key Table for the correct button for your air conditioner brand.

 ON/OFF	 TEMP	 TEMP	 WIND	 MODE	 M, SWING
GREE/ HAIER	MIDEA/TOSHIBA CHANGHONG	SHARP/ KELON	MITSUBISHI/ OTHERS	LG/SAMSUNG	HITACHI/ PANASONIC
 A, SWING	 TIME ON	 TIME OFF	 F, Cool	 F, Heat	
SANYO/ HISENE	CHIGO/ DAIKIN	Fujitsu/ Carrier	CHUNLAN/ AUX	Shinco/ AUCMA	


B. Manual Code Input




Power on the air conditioner manually. Locate your air conditioner brand and its corresponding code in the Code Table (e.g. Haier).



Press and hold the SET button for about 3 seconds until the code starts blinking on the LCD screen. Use the Temperature ▲/▼ buttons to scroll through codes until the correct one appears and the air conditioner responds (e.g. turns on).



Press OK to confirm the code which will stop blinking





Test the remote control functions.

- If they work correctly, the setup is complete.
- If not, repeat steps 2-3 with the next code.


C. Digital Automatic Search

Use this mode if you're unsure of your air conditioner brand or if it's not listed in the code table.

Aim the remote control at the air conditioner. **Press and hold the SET button** for 5 seconds, then release. The remote will enter **auto-search mode**, sending signals continuously while the code blinks and increases. When the air conditioner responds with a **buzzer sound**, **press any key to pause**, then **press OK** to confirm.



After your air conditioner turns on, **test the functions** of the remote control. If they do not work correctly, **repeat the setup steps** until the remote can fully operate your air conditioner.




Test all remote functions (excluding Temperature and SET buttons).

- If they work, the setup is complete.
- If not, press SET again to continue the search.

/ Set Time Function

To set the clock time:

1. **Press and hold the CLOCK button** for approximately 3 seconds until the time display begins to blink.
2. Use the **Temperature ▲/▼ buttons** to adjust the current time.
3. Press the **CLOCK button** again to confirm and exit the time setting mode.



/ Timing ON/OFF Function

To configure the air conditioner's timer:

1. Press the **TIME ON** or **TIME OFF** button.
2. The air conditioner's timer indicator light will turn on, confirming that it has entered timed operation mode.

Note:

The **Timer Power-On** function can only be set when the remote control is in the **power-off state**. This feature is only available for air conditioner models that support **built-in timer power-on**. If your air conditioner does **not** support this feature, the remote control **cannot enable automatic power-on**.

/ **General Usage Notes**

- This remote control will function properly **only if the air conditioner's receiver is working normally.**
- If the remote control will **not be used for an extended period**, please **remove the batteries** to prevent leakage or damage.
- If the remote control behaves abnormally due to incorrect operation, it may cause an **internal program error.**

In such cases:

1. Remove the batteries.
2. Wait approximately **35 minutes.**
3. Reinstall the batteries, this may restore normal functionality.

/ Warm Tips

Brand	Code	Brand	Code	Brand	Code
ACSOM	980	DAOTIAN	821-824	INYCIN	475-483
ADC	861	DELONGHI	900	JIANGNAN	359
AIDELONG	293-295	DUNAN	336	JIALE	358
AITE	296-299	DONGXIA	334-335	JMSTAR	360
AKIRA	796-797	DONGXINBA	260-268	JINBEIJING	361-362
AMCOR	501,508,509,532 973,978,979	ELCO	982	JINDA	491-492
		ELECTER	981-986	JINSONG	363-365
AMICO	982	ELECTROLUX	471-474	JOHNSO	282
ALPIN	989-991,998	FEDDERS	878	KANGILI	368-370
AUCMA	210-229	FEIEDRICH	879	KELONG	110-119
AUX	180-199	FEIGE	829-830	KLIMATAIR	797-800
AOKE	301-302	FEILU	240-249	KONKA	366-367
AOLI	300	FERROLI	901	KRIS	804-805
APTON	862	FIRST	864	KT02 D001	283
AZURE	000-999	FRESTECH	270 279	KT02 D002	284
BAIXUE	299	FEDDERS	878	KTY001	285
BEIJINGJINGMAX	304	FUJITSU	700-719	KTY002	286
BIG-THIMB	331	GALANZ	140-149	KTY003	287
BOERKA	630	GARRIER	690-699	KTY004	288
BOERKA	305-306		890-899	KTY005	289
BOSHI	310	GEER	342-343	LG	600-609
BOSHI GAO	308-309	GLEE	280	LIANGYU	780
BORLER	307	GOLDSTAR	303	LIKEAIR	386-387
BLUE STAR	000-999	GODREJ	000-999	LITTLESWAN	453
CAIXING	311	GREE	000,020-039	LONGHE	861
CARRIER	000-999	GULANGDA	345-346	LOREN-SEBO	801-803
CHANGFENG	190	GUQIAO	344	LLYOD	000-999
CHANGFU	835-838	HAIER	001-019	MCQUAY	790-795
CHANGLING	312-323	HEL TON	863	MD	040-059
CHANCHONG	60079	HEMIL TON	95	ME I LING	388-391
CHENGYUAN	324	HI CON	391-392	MINGKING,BOIIN	290
CHIGO	080-099	HI SENSE	230-239	MITSUBISHI	551-599
CHUANGHUA	325-328	HITACHI	640-659	MITSUKA	904
CHUANVAN	861	HONGYI	347	NATIONAL/Panasooi	660-689
COLROLLA	861	HUABAO	100-109	NIKKO	810-811
CHINLAN	170-179	HUAGAO	348	NISO	398-399
CONSUL	993	HUAKE	349-350	NISO	497
CONROWA	337-341	HIUAMEI	351-352	NORCA	994
CORONA	760-769	HUANGHE	353	OLYMPUS	995-996
CROWN	861	HUALING	150-169	OPAL	997
DAEWOO	332-333	HUAWEI	281	ONIDA	000-999
DAIKIN	710-759	HUIFENG	354-356	O.GENERAL	000-999
DAJI NX INC	329-330	HUIFENG	357,360	PANDA	464-466
DAKE	861	HYUNDAI	780-789	PANASONIC	000-999

Brand	Code	Brand	Code
PEREG	998	TADIRAN	501,508,509
PINSMANG	290		532,630,969
PILOT	902		978,979,991
PLYI	862	TAJ YA	862
QIXING	393	TCL	120-139
RAYBO	371-383	TEAC	850-859
RHOSS	903	TECO	831-834
RICAI	394	TIANJINXONGTIA	424
RIJIANG	395-397	TIANYUAN	425-428
ROWA	383-385	TOBO	250-269
SACON	414	TONGLI	429-430
SAMSUNG	610-629	TOYO	825-828
SANYO NEC	500-550,860	TOSHIBA	630-639
SANZUAN	190	TOTALLINE	000-999
SAPORO	801	TRANE	812-810
SAST	450-4152	UNI-AIR	368-369
SENSOR	860	UTTLEDUCK	454-456
SERENE	499	VOLTAS	000-999
SHAMEI	400	VIDEOCON	000-999
SHANGUNG	403-409	WANBAO	431-433
SHANYE	862	WANGZI	861
SHANXING	401-402	WEILI	434-443
SHARP	720-739		553-576
SHENBAO	410-411	WEITELI	444
SHENGFENG	412	WH IRLPOOL	770-774
SHENGFENG	413	WUFENG	445-446
SHINCO	200-209	XINGHE	462-463
SHINING	415	XINLE	457-460
SHUANGLU	416-418	XI LENG	448-449
SIGMA	447	XI NILING	461
SOGO	291	XIONGDI	862
SONGLINXIA	862	YAIR	467,471,041
SONGXING	419	YAOMA	470
SOVA	292	YIDONG	499
SOVA	420	YORK	775-779
SOWA	862-863	YUTU	484-490
SOYEA	421-422	ZHONGYI	493-494
SPEED	987	ZUODAN	495
SRTC	423	DIY	044,090
STARICHT	880		092,095
SUNBURG	817-820	OTHER	496,498,821
TADIAIR	501,508,509,532		828,839-849
			865-877,905
			976,999

* This company reserves the right to interpretation of the User's Manual. Design and technical parameters may vary without notice.