
J.BURROWS

ASSEMBLY INSTRUCTIONS

MATRIX 1500/1800mm CORNER WORKSTATION DESK JBMCDT15WE,MOWSFR15C1,MOWSFR15C2 JBMCDT18WE,MOWSFR18C1,MOWSFR18C2



This design and instruction booklet is subject to copyright. www.officeworks.com.au

3 Carton

Customer Service Contact Details




Spare Parts & Hardware 1300 OFFICE (1300 633 423).

People Required



General Advice





CAUTION: Do not use tools other than those required, as this can damage your new item.

NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact 1300 OFFICE (1300 633 423).
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION

- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all bolts and screws are firmly secured.
- Check that all bolts and screws are securely tightened at least every 4 months.


WARNING

- If parts are missing, broken, damaged or worn, stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.


DANGER

CHILDREN MUST BE SUPERVISED.


Parts located in carton - MOWSFR15C1/MOWSFR18C1



Parts located in carton - MOWSFR15C2/MOWSFR18C2



Parts located in carton - JBMCDT15WE/JBMCDT18WE




Hardware located in carton-MOWSFR15C1/MOWSFR18C1

			(1)		
A x 1 (5mm)	Bx8 (M6x30)	C x 12 (ST4.8 x20)	Dx8	Ex 1	Fx2

Hardware Spare Parts number - HWWSFR15C1/HWWSFR18C1


<u> </u>		∞∞∞∞	
A x 1 (5mm)	Bx8 (M6x30)	C x 12 (ST4.8 x20)	D x 8


Hardware Spare Parts number - HWMACBLCVR























Warranty 8 years

Product Warranty – valid for Australian customers only
Officeworks Ltd warrants that this product will be free from defects and work as intended for 8 years from the date of purchase by the original customer.

If the product has any defects or does not work as intended during the Warranty Period, Officeworks will, at its election and at its expense, repair or replace the product.

This warranty does not apply:

- To cosmetic damage;
- To damage caused by consumables used in connection with the product (such as cleaning products);
- Where the product has not been used in accordance with all provided instructions;
- To damage arising from fair wear and tear;
- Where the product has not been subject to reasonable use;
- Where the product has been intentionally or negligently damaged; and/or
 if the customer has attempted to repair the product.

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

This warranty is provided in addition to any rights you may be entitled to under the Competitions & Consumer Act 2010.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Thank you for your purchase. Please retain your receipt to validate warranty. If you would like to know more about our furniture products, please visit www.officeworks.com.au