



BrewGo

The Rechargeable Portable Coffee Maker

Instant, Aromatic, Anywhere!



INSTRUCTION MANUAL

Please read this manual carefully before using, and keep it for future reference.

QBPCM12V

CONTENTS

General Safety	4
Product Overview	7
Installation	8
Coffee Extract	8
Troubleshooting	10
Specification	11
Customer Support	Last Page

GENERAL SAFETY

Please read this manual carefully before using the coffee maker.

Keep the manual, completed warranty card, purchase receipt, and product packaging for future reference.

Following the safety instructions helps reduce the risk of fire, electric shock, and personal injury when used correctly.

Be sure to follow all guidelines and pay attention to all warnings provided.

IMPORTANT INFORMATION

Do not expose the coffee maker to rain, moisture, or submerge it in water.

Do not tamper with, modify, or disassemble the coffee maker in any way.

Use only the accessories and attachments recommended by the manufacturer.

Avoid spilling or splashing liquids directly onto the coffee maker or its charging components.

- This appliance must not be exposed to dripping or splashing, and no objects filled with liquids, such as vases, should be placed on it. For dry location use only.
- Do not place open flame sources, such as candles, on or near the product.
- This appliance is not intended for use by individuals (including children) with reduced physical, sensory, or mental capabilities, or those lacking experience and knowledge, unless they are supervised or properly instructed. Children should be supervised to ensure they do not play with the appliance.
- Do not immerse the base of the coffee maker in water or any other liquid.
This product is not waterproof and improper handling may cause damage.
- If the power cord is damaged, it must be replaced by the manufacturer, an authorized service agent, or a similarly qualified professional to avoid potential hazards.

GENERAL SAFETY (Cont.)

- This product is compatible with TYPE-C mobile chargers. Once fully charged, the indicator light will remain on.
- Do not open the lid or insert hands or objects into the coffee maker while it is operating, as this may cause injury or damage.
- Before cleaning, turn off the power and disconnect from charging.
- Do not immerse the base or any electrical parts in water, as this will damage the internal components.
- This coffee maker is designed for short brewing cycles. Avoid continuous operation or excessive use to prevent overheating and ensure long-term performance.
- Do not disinfect any parts in a microwave or with water above 80°C.
- Do not clean accessories in a dishwasher or with abrasive materials such as steel wool or harsh chemicals.
- Keep out of reach of children. This product should only be used by individuals familiar with its operation or under supervision.
- This coffee maker is intended for personal or household use only.
- In case of malfunction, contact customer service. Do not attempt to repair or disassemble the product yourself, as this will void the warranty.

WARNING: THIS PRODUCT IS POWERED AND MAY ACTIVATE. PLEASE EXERCISE CAUTION WHEN UNPACKING, PREPARING BEVERAGES, OR DURING USE. DO NOT PLACE HANDS NEAR ANY HEATING OR DISPENSING COMPONENTS TO AVOID INJURY. THE APPLIANCE SHOULD NOT BE USED UPSIDE DOWN OR INVERTED.

GENERAL SAFETY (Cont.)

CAUTIONS!

CAN'T WASH HOST PART

Please read the instruction manual before first use and keep it if necessary.

CAUTIONS!


- Don't touch red pad on the cap when it's heating.
Keep children away from device when it's heating.
- Don't heat the devices if there is no water inside, even though there is anti-dry heat protection for 145°C. At the status of anti-dry heat protection, LED flashes 5S and peeps 5S.
- Clean the device and keep it dry after use.

CHARGING

- 1 .Please charge the device in time when red LED running.
Red LED is running when it's in charging. Green LED will be on after fully charged.
2. For USB cable charging, it cannot work until it is fully charged.

LED COLOR	WORKING STATUS
Red LED flash 5S	Heat overtime
Orange running LED	Heating
Green LED on	Extraction

PRODUCT OVERVIEW



Caution: Any part of this product are not dishwasher safe and should not be washed with strong chemicals. Warm water with a little bit of soap recommended

INSTALLATION

Please check if all the indicator lights are on before initial use. Please clean the cup body and base before use. This blender has double safety protection. It will work when the cup body is completely fixed into the base by screwing, then double press the power button



Big Capsule




Small Capsule



INSTALLATION (Cont.)

Coffee powder



COFFEE EXTRACT

You can choose cold water or hot water for extract. For cold water, please operate as below steps:

1. Take cap off, pour cold water into water container then close the cap.
2. Press power button once to check battery level (green LED on), then long press power button to extract cold coffee (green LED running), Red LED is running when battery level below 25%.
3. If heat the cold water,press button twice to heat the water to 92°C within 5mins (orange LED breathing), it peeps 4 times and automatically extract hot coffee for 60S (green LED running).

For hot water, please operate as below steps

1. Take cap off, pour hot water into water container then close the cap.
2. Press power button once to check battery level (green LED on), then long press power button to extract hot coffee for 60S (green LED running).

TIP For extracting better and richer coffee, it is suggested to use hot water.

TROUBLESHOOTING

Malfunction	Analysis	Troubleshooting
Red light is on for 8 seconds	Ran out of battery	Charge it for 3 to 5 hours to make sure that it gets a full recharge.
Red light flashes slowly with buzzer sounds for 5 seconds	Heat time over 15 mins, device stop working	Restart.Double click power button to heat water.
Red light flashes quickly with buzzer sounds for 5 seconds	Over-heating protection	Take cap off to cool it down for 5 mins.Then re-heat by double clicking power button.
Extraction of water only	Big capsule or small capsule is not pricked well	Twist the big capsule holder tightly to the end until it can't be screwed.
Extracted ground coffee is with residue	Coffee powder is overflowed on the holder edge	Make sure no overflow coffee powder around the powder holder and use a spoon to press coffee powder tightly for a better extraction.

SPECIFICATIONS

Model	QBPCM12V
Input	5V/2A
Battery Type/Capacity	8650/2500mAh*3
Charging Time	About 3.5 hours
Single Working Time	30S
Boiled Time	5 mins
Extract time	60S
Dimensions	83.5 (w) x 83.5 (d) x 245.5 (h) mm
Gross Weights	kg



CUSTOMER HELPLINE: info@ayonz.com / 02 8279 8606

DISTRIBUTED BY: Ayonz Pty Ltd

