



High Temperature Glue Gun SMHTGG

Instruction Manual

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

BEFORE FIRST USE

CAUTION:

- This Glue Gun is suitable for indoor domestic use.
- DO NOT TOUCH THE NOZZLE OR FRESHLY DISCHARGED GLUE.
- If the nozzle or glue does come in contact with the skin, apply cold water to the affected area immediately. Do not try to remove the glue from the skin, seek medical attention if required.
- Place gun on its stand when turned on - but not in use. Do not leave the glue gun unattended when in use.

OPERATING INSTRUCTIONS

PREPARATION

- Use a desk mat to protect your working surface. Ensure the cord is fully unwound.
- Ensure the work piece to be glued is not colder than 5°C or warmer than 50°C.
- It is recommended to test glue onto a small inconspicuous place as different surfaces may be affected differently. Ensure surfaces are clean for the best bonding.
- Allow the glue gun to preheat & reach operating temperature (approximately 5 minutes).
- Keep the cord away from the gun and nozzle.
- Insert the glue sticks into the back of the glue gun.
- Press the trigger several times until the glue stick is firmly set into the inlet tube & allow to heat up (approximately 2 minutes).
- The glue gun has a drip-control function, this prevents the glue from dripping when the gun is at operating temperature.
- Do not leave the Glue Gun on for long periods of time. Use the trigger at 15min intervals.
- Do not use glitter or colour glue sticks at high temperature. The drip-control function will not work properly.

USING THE STAND

- The glue gun **must** be placed on its stand when not in use.
- Push the stand "down" and place on a flat surface when temporarily not in use.
- Do not lay the glue gun on its side whilst hot.
- Turn off & unplug from power supply when not in use.

CHANGING GLUE STICKS

- Do not attempt to remove the unused portion of a glue stick from the glue gun.
- If switching glue stick types, fully empty the original glue stick via the melting chamber by squeezing the trigger. As the original glue stick melts through the chamber insert the new glue stick behind the original glue stick until it flows through.

CARE & STORAGE

- The HOT nozzle can cause damage so allow it to cool completely before storing.
 - DO NOT use flammable solvents for cleaning!
 - After use do not wrap the cord around the glue gun as this may cause the cord to fracture. Coil cord loosely by the side of the glue gun in storage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Never use the glue gun with a damaged cord.