



User Manual

Stilford Electric Height Adjustable Desk 1400mm / 1600mm / 1800mm

Stilford Electric height adjustable workstation 1800mm

Stilford electric adjustable back to back desk 1600mm / 1800mm

Item#

JBSHAD18WO/ BW / BO

JBSHAD16WO/ BW / BO

JBSHAD14WO

JBSHWS18WW

JBSHBB18WW / BO



JBSHBB16WW / BO

Learning and Reset Process:

After assembling the desk please complete the following Learning & Reset Process before use.

1. When power is plugged in for the first time (or when power has been cut off to the desk temporarily such as power shortage or changing power outlets), the display will flash "SET".
2. Learning: Press the "s" button and the up arrow button at the same time for 2 seconds. The display will flash "SET". The table will then starts to run the full stroke down and up in order to record the positions of upper and lower limits. The table will go down to bottom position, up to top position and then down to bottom position again. After the learning process has finished the display will show "071".
NOTE: the desk will need to go through this learning process every time the power is cut off to the desk. Do not press any button whilst the desk runs the length as this will end the process and will need to be restarted.

General Operation:

1. Keep pressing button , the table will move up to the upper limit position.
2. Keep pressing button , the table will move down to the lower limit position.
3. Standby mode: Display will be off automatically if there is no any button pressed in 20 seconds.

Memory Function:

1. Press button "s" for 2 seconds until the screen flashes. Followed by pressing button "1". The screen will show "001". Release the button and the height number will be shown on screen and memorised as position 1.
2. The operation for memorized positions 2, 3, and 4 is similar to the one for position 1.
3. When the screen flashes after pressing the "s" button for 2 seconds, if button 1 – 4 are not pressed within 10 seconds, the screen will stop flashing and leave the memory mode.
4. Press and hold any button "1", "2", "3" or "4", to move the table height automatically to the memorized position

Protection function:

1. OVER HEATING PROTECTION: Display will show "HOT" and halt operation for 1 minute if the desks is in continuous movement for 300 seconds.
2. OVER LOADING PROTECTION: The display will show "E01" when table is loaded with too much weight. Remove some weight before attempting to change the desk height again.
3. ANTI-PINCH PROTECTION: During moving up and down, the table will move back then stop if a sudden resistance is detected the display will show "E16".