




ASSEMBLY INSTRUCTIONS


STOCKHOLM TWIN CABINET DESK

OTSTHOCOBK
OTSTWCWBK

A



B



Go to page 21

This design and instruction booklet is subject to copyright.
www.officeworks.com.au

2 Cartons

For spare parts or hardware call 1300 OFFICE(1300 633 423)

Estimated Assembly Time: 90minutes

Assembly Video

- To view an assembly video, go to <https://www.officeworks.com.au/>
- Search the product by item code or name:



- Click on the icon to watch the video.




Customer Service Contact Details



Spare Parts & Hardware

1300 OFFICE(1300 633 423)


People Required



General Advice



Tools Required



CAUTION: Do not use tools other than those required, as this can damage your new item.

NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact 1300 OFFICE(1300 633 423).
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION

- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all bolts and screws are firmly secured.
- Check that all bolts and screws are securely tightened at least every 4 months.








WARNING

- If parts are missing, broken, damaged or worn, stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.



















DANGER

- CHILDREN MUST BE SUPERVISED.





















Parts Located in Carton - OTSTHOC1OB/OTSTWC1WB

 ④ 2pcs	 ⑨ 1pc	 ⑩ 1pc	 ⑪ 2pcs	 ⑰ 2pcs
 ②③ 1pc	 ②④ 1pc			
















Parts Located in Carton - OTSTHOC2OB/OTSTWC2WB

 ① 1pc	 ② 1pc	 ③ 2pcs	 ⑤ 4pcs	 ⑥ 4pcs
 ⑦ 1pc	 ⑧ 1pc	 ⑫ 1pc	 ⑬ 1pc	 ⑭ 2pcs
 ⑮ 2pcs	 ⑯ 2pcs	 ⑱ 1pc	 ⑲ 1pc	 ⑳ 1pc
 ㉑ 2pcs	 ㉒ 1pc	 ㉕ 1pc		


Hardware Located in Carton - OTSTHOC2OB/OTSTWC2WB

 A M6x35mm 20pcs	 B Φ 15x12mm 12pcs	 C Φ 6x30mm 32pcs	 D Φ 4x30mm 12pcs
 E Φ 3x12mm 32pcs	 F 350mm 2pcs	 G (CL) 350mm 2pcs	 G (CR) 350mm 2pcs
 G (DL) 350mm 2pcs	 G (DR) 350mm 2pcs	 H Φ 4x35mm 8pcs	 I M6x40mm 8pcs
 J Φ 15x9mm 8pcs	 K 1pc	 L 2pcs	 M Φ 4x14mm 12pcs
 N 4pcs	 O Φ 3x14mm 8pcs	 P 8pcs	 Q Φ 5x30mm 16pcs





Hardware Spare Part number - HWSTWCABDK

A  M6x35mm 20pcs	B  Φ 15x12mm 12pcs	C  Φ 6x30mm 32pcs	D  Φ 4x30mm 12pcs
E  Φ 3x12mm 32pcs	H  Φ 4x35mm 8pcs	I  M6x40mm 8pcs	J  Φ 15x9mm 8pcs
K  1pc	L  2pcs	M  Φ 4x14mm 12pcs	N  4pcs
O  Φ 3x14mm 8pcs	P  8pcs	Q  Φ 5x30mm 16pcs	


Hardware Spare Part number - HWSTCKFDRU




Hardware Spare Part number - HWSTCKSDRU

G (CL)  350mm 2pcs	G (CR)  350mm 2pcs	G (DL)  350mm 2pcs
G (DR)  350mm 2pcs		


Hardware Spare Part number - HWSTCKHMR



A






B




Go To Page 21


Step 1





Step 2





Step 3





Step 4





Step 5





Step 6





Step 7





Step 8





Step 9







Step 10




Step 11





Step 12





Step 13






Step 14






Step 15





Step 16





Step 17




Step 18





Step 19





Step 20





Step 21




Step 22




Step 23






Step 24





Step 25




Step 26




Step 27



Step 28



Place the assembled drawers into the frame by aligning the slide runners of the drawers with the runners on the unit. If the drawer does not slide in smoothly, remove the drawer to ensure the alignment on both sides are correct. Push the drawers all the way into the unit until it stops.




MAXIMUM WEIGHT CAPACITY

Desktop 50kg
Stationery drawer 3kg
Filing drawer 15kg


⚠ CAUTION: This product is intended to hold the maximum weight indicated. Exceeding the maximum weight will result in instability and may cause injury.

Thank you for your purchase. Please retain your receipt to validate warranty. If you would like to know more about our furniture products, please visit www.officeworks.com.au




How to adjust the door





B





Step 1





Step 2





Step 3





Step 4





Step 5





Step 6





Step 7





Step 8






Step 9




Step 10





Step 11





Step 12






Step 13





Step 14





Step 15




Step 16




Step 17






Step 18







Step 19





Step 20





Step 21




Step 22






Step 23





Step 24




Step 25




Step 26



Step 27



Place the assembled drawers into the frame by aligning the slide runners of the drawers with the runners on the unit. If the drawer does not slide in smoothly, remove the drawer to ensure the alignment on both sides are correct. Push the drawers all the way into the unit until it stops.



MAXIMUM WEIGHT CAPACITY

Desktop 50kg
Stationery drawer 3kg
Filing drawer 15kg

⚠ CAUTION: This product is intended to hold the maximum weight indicated. Exceeding the maximum weight will result in instability and may cause injury.

Warranty 3 years

Product Warranty – valid for Australian customers only

Officeworks Ltd warrants that this product will be free from defects and work as intended for 3 years from the date of purchase by the original customer.

If the product has any defects or does not work as intended during the Warranty Period, Officeworks will, at its election and at its expense, repair or replace the product.

This warranty does not apply:

- To cosmetic damage;
- To damage caused by consumables used in connection with the product (such as cleaning products);
- Where the product has not been used in accordance with all provided instructions;
- To damage arising from fair wear and tear;
- Where the product has not been subject to reasonable use;
- Where the product has been intentionally or negligently damaged; and/or if the customer has attempted to repair the product.

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

This warranty is provided in addition to any rights you may be entitled to under the Competitions & Consumer Act 2010.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Thank you for your purchase. Please retain your receipt to validate warranty.

If you would like to know more about our furniture products, please visit www.officeworks.com.au