


STILFORD

ASSEMBLY INSTRUCTIONS

TONSBERG DESK

OTTON180DK



This design and instruction booklet is subject to copyright.
www.officeworks.com.au

2CTNS

For spare parts or hardware call 1300 OFFICE. (1300 633 423)

Estimated Assembly Time: 90 minutes


Customer Service Contact Details



Spare Parts & Hardware

1300 OFFICE (1300 633 423)


People Required



General Advice



Tools Required



CAUTION: Do not use tools other than those required, as this can damage your new item.

NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact 1300 OFFICE(1300 633 423)
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION

- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all bolts and screws are firmly secured.
- Check that all bolts and screws are securely tightened at least every 4 months.




















WARNING

- If parts are missing, broken, damaged or worn, stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.



DANGER

- CHILDREN MUST BE SUPERVISED.

















Parts located in Carton-OTTON18C1

| | | |
|--|--|---|
| <div>①</div> <div></div> <div>x1pc</div> | <div>②</div> <div></div> <div>x2pcs</div> | <div>③</div> <div></div> <div>x1pc</div> |
| <div>④</div> <div></div> <div>Left</div> <div>x1pc</div> | <div>⑤</div> <div></div> <div>Right</div> <div>x1pc</div> | <div>⑥</div> <div></div> <div>Left</div> <div>x1pc</div> |
| <div>⑦</div> <div></div> <div>Right</div> <div>x1pc</div> | <div>⑧</div> <div></div> <div>Left</div> <div>x1pc</div> | <div>⑨</div> <div></div> <div>Right</div> <div>x1pc</div> |
| <div>⑩</div> <div></div> <div>x1pc</div> | <div>⑪</div> <div></div> <div>x1pc</div> | <div>⑫</div> <div></div> <div>Left</div> <div>x1pc</div> |
| <div>⑬</div> <div></div> <div>Right</div> <div>x1pc</div> | <div>⑭</div> <div></div> <div>Left</div> <div>x2pcs</div> | <div>⑮</div> <div></div> <div>Right</div> <div>x2pcs</div> |
| <div>⑯</div> <div></div> <div>x2pcs</div> | <div>⑰</div> <div></div> <div>x2pcs</div> | <div>⑱</div> <div></div> <div>x2pcs</div> |
| <div>⑲</div> <div></div> <div>x1pc</div> | | |


Parts located in Carton-OTTON18C2

| | |
|---|---|
| <div>20</div> <div></div> <div>x2pcs</div> | <div>21</div> <div></div> <div>x2pcs</div> |
|---|---|

Hardware located in Carton-OTTON18C2
Hardware Spare Parts number-HWTONSHW


| | | | | | |
|---|---|---|--|--|--|
| <div>A</div> <div></div> <div>x30pcs</div> | <div>B</div> <div></div> <div>x30pcs</div> | <div>C</div> <div></div> <div>x28pcs</div> | <div>D</div> <div></div> <div>x20pcs</div> | <div>E</div> <div></div> <div>x2pcs</div> | <div>F</div> <div></div> <div>x6pcs</div> |
| <div>H</div> <div></div> <div>#4*14 x48pcs</div> | <div>I</div> <div></div> <div>x6pcs</div> | <div>J</div> <div></div> <div>x6pcs</div> | <div>K</div> <div></div> <div>x6pcs</div> | <div>L</div> <div></div> <div>x2pcs</div> | |
| <div>M</div> <div></div> <div>#4*16 x8pcs</div> | <div>N</div> <div></div> <div>x6pcs</div> | <div>O</div> <div></div> <div>#4*35 x12pcs</div> | <div>P</div> <div></div> <div>x1pc</div> | <div>Q</div> <div></div> <div>x4pcs</div> | |

Hardware Spare Parts number-HWTONSDR


| |
|--|
| <div>G</div> <div></div> <div>x4pcs</div> |
|--|

Step1

A




x10pcs




Step 2

A




x10pcs






Step3

A




x10pcs




Step 4



C





x4pcs





Step5



Step 6





Step 7






Step 8、9 will be used

Step 27 will be used



Step 8




Step 9

H



#4*14 x6pcs




Step 10


B



x4pcs




4x



Step 11 ^B




x7pcs



Step 12 ^B




x7pcs



Step 13 B




x4pcs





Step 14 B





x2pcs





Step 15





Step 16




Step 17




Step 18



Upwards




Downwards




Not over-tightened

For the holes on cross beam,
please make sure the flat holes
facing upwards, while the sink
holes facing downwards.


Step 19



To ensure that I is accurately placed into the corresponding hole and not over-tightened




Step 20





Tighten all the screws from step 17 to 18.

Step 21



Tighten all the screws from
step 19





Step 22





Step 23




Step 24



Step 25



Step 26




Step 27

H




#4*14 x12pcs







Step 28

Move the ball bearing to the front.




Step 29



Caution: Push the drawer hard to the end.

Step 30

MAXIMUM WEIGHT CAPACITY



NOTE: Desktop 80 kg ,
stationery drawer 5 kg



CAUTION: This product is intended to hold the maximum weight indicated.
Exceeding the maximum weight will result in instability and may cause injury.

Warranty 15 years

Product Warranty – valid for Australian customers only

Officeworks Ltd warrants that this product will be free from defects and work as intended for 15 years from the date of purchase by the original customer.

If the product has any defects or does not work as intended during the Warranty Period, Officeworks will, at its election and at its expense, repair or replace the product.

This warranty does not apply:

- To cosmetic damage;
- To damage caused by consumables used in connection with the product (such as cleaning products);
- Where the product has not been used in accordance with all provided instructions;
- To damage arising from fair wear and tear;
- Where the product has not been subject to reasonable use;
- Where the product has been intentionally or negligently damaged; and/or if the customer has attempted to repair the product.

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

This warranty is provided in addition to any rights you may be entitled to under the Competitions & Consumer Act 2010.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Thank you for your purchase. Please retain your receipt to validate warranty. If you would like to know more about our furniture products, please visit www.officeworks.com.au