

INSTRUCTION MANUAL

RGB GAMING MOUSE MODEL: STRIKE MSE11




Windows®XP or later

Compatible with

• 1 •



Product Functions




Back



Usage Instructions

Press key to adjust DPI.

Green



Light

There

Scroll Light

Red

11 liaht modes

• 2 •				

4800

Blue

8400

Yellow

Purple

White



Press DPI+left button key for 1 second together to switch light mode.

* PMW3360 IC, up to 12000DPI * HUANO switches, 20 million click lifetime for both left and right key

- * Ergonomic design, comfortable use
- * 1.5m USB PVC cable with magnet ring

* 6D RGB gaming mouse

- * Polling Rate: 125-250-500-1000Hz * Maximum Acceleration: 50G
- * Rating: 5V==100mA
- * Max. Speed: 634cm/sec
- * Plug and play
- **Packaging Contents**
- RGB Gaming Mouse x 1
 Instruction Manual x 1

location.

1. Visit www.officeworks.com.au/drivers to download the customisable drivers. 2. Once you have followed the installation steps, the driver icon will show up in your standard

• 3 •

3. Once you click on the driver icon, it will bring up the driver menu as shown below. Click on "Keys" to change your mouse buttons.

Advanced Driver Features Drivers are compatible with Windows only.




4.Click on "Performance" to change the speed of your mouse cursor as well as adjust DPI

5. Click on "Light" to change the light mode and apply it, or "Reset". You can select from any of the

5 different profiles listed on the left of the screen.

6. Click on "Macro" to assign macro keys for your mouse.



To prevent fire or shock hazard, do not expose the unit to rain or moisture. To avoid electrical shock, do not open the cabinet, refer to service agent or qualified engineer only.

Officeworks Ltd warrants that this product will be free from defects and work as intended for 3

WARNING

years from the date of purchase by the original customer. If the product has any defects or does not work as specified during the Warranty Period, Officeworks will, at its election and at its expense, repair or replace the product.

Valid for Australian Customers Only

• where the product has not been used in accordance with all provided instructions; • to damage arising from fair wear and tear; · where the product has not been subject to reasonable use;

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

amount to a major failure.

This warranty does not apply: · to cosmetic damage;

Product Warranty –

• if the customer has attempted to repair the product.

where the product has been intentionally or negligently damaged; and/or

· to damage caused by consumables used in connection with the product;

This warranty is provided in addition to any rights you may be entitled to under the Competition & Consumer Act 2010. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have

the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not

OFFICEWORKS LTD 236-262 EAST BOUNDARY ROAD EAST BENTLEIGH VIC 3165 AUSTRALIA

Windows is a trademark of the Microsoft Corporation in the United States and other countries.

• 6 •