
J1
DC Power in (micro USB) underneath
J2
HDMI (Type A)
CN8
3.5mm AUDIO
J13
Network RJ-45
J7
Battery Connector
SW1
Reset
J5
microSD slot (underneath)
P7
SPI0 Port
P5
SATA
CON15
Camera
P4
SATA Power
J11
Digital I/O
J12
Analog input
U16
IR
SW2
Upgrade (not currently implemented; reserved for future expansion)
J8
Digital I/O
J9
Power port
P3
Debug Port
CON25
LCD (LVDS)
P6
SPI1 Port
SW3
Back
P10
GPI0
SW4
Home
SW5
Menu
P2
Wireless Connection Module Interface
J3
USB OTG
On the go
micro USB
J4
Host USB (USB 2.0)
USB Type A