

Model: WCUV10 UV Steriliser with Wireless Charging User Manual ver 1.1





Compatibility

Compatible with Qi-enabled devices* including

• iPhone 12 Pro/Max Samsung Note 20/10/9 • iPhone 12/mini Google Pixel 5/4/3 • iPhone 11 Pro/11 Sony Xperia XZ3/XZ2 • iPhone SE/XS/XS Max/XR Xiaomi Mi 10/v 9 • iPhone X/8/8 Plus I G G8S/G7 ThinQ Samsung S20/S10/S9/S8 I G V30+/V40

Features

kill up to 99.9% of harmful germs, viruses and bacteria • UV light is used to kill E.coli, Staphylococcus and Candida Albicans surface bacteria that live on your phone, keys, AirPods & iewellerv • 15 minutes is all it takes to complete the sterilisation process & sterilisation will stop automatically when the lid is open for safety • Supports 7.5W wireless fast charging for iPhone 8 or later# • Supports 10W wireless fast charging for compatible devices such as the Samsung Galaxy Series and more# • Supports 5W standard wireless charging for all Qi enabled devices • No need to remove your protective case. Works with most cases up to 3mm thick LED indicator to show charging status

• Certified by global leading certification company TŰV SŰD to

temperature control, strict voltage regulation & short circuit protection • Includes 1.5m USB-A to USB-C charging cable

• Full safety protection for your devices with Qi certified

* Check with device manufacturer for Qi wireless compatibility # When connected to a QC 2.0 or 3.0 wall charger (not included)

Specifications

 Wireless Standard: WPC/Qi (v1.2.4) Input: DC 5V/2A 9V/2A

 Wireless Stand Output: 10W / 7.5W / 5W Working Frequency: 110 to 205KHz

 Charging Distance: 3 to 8mm Charging Efficiency: >70%

• Size: 214mm (L) x 120mm (W) x 34mm (H) • Weight: 325a

Certifications: RCM, RoHS, UN38.3

UV Steriliser Operation

Steriliser to a USB wall charger (USB wall charger not included) • Remove the lid and place you phone, keys, iewellery or other items into the UV Steriliser Replace the lid and ensure it is on correctly • Press the power button, the LED will be red and a 15 minute sterilisation cycle will begin • When sterilisation is complete the LED will turn off and you can safely remove your items

• At any time during the sterilisation cycle, you can remove the

• You can sterilise items and charge your phone at the same

lid and sanitising will automatically stop for safety

Using the included USB-A to USB-C cable, connect the UV

time. During this process, the LED will be a lighter green

saving trickle charge mode

Wireless Charger Operation • Place your Qi enabled wireless phone on the centre of the lid and your phone should start charging automatically • The LED will be green to indicate wireless charging

• When your phone is fully charged, the Smart IC enables energy

registered in the U.S. and other countries. The 'Qi' Symbol is a trademark of the Wireless Power Consortium.

















Important Safety Instructions

avoid short circuit damage and leakage

avoid magnetic failure

interference

charging dock

odour

• Only use original or reputable third party chargers and cables

• Do not use in extreme hot, humid or corrosive environments to

• Misuse, dropping or excessive force may cause damage to the

• Do not use the product if it is damaged or emits a suspicious

• Unplug the product from power sources when not in use

Please Note: When wirelessly charging a device, the wireless

charger and your device may feel warm. This is a normal

operating condition and should not be cause for concern.

• Only use the product for the specified purpose of use

• Do not get wet to avoid causing short circuit damage and

• Do not place too close to magnetic strip or chip ID card to

• Do not place within 20cm of implantable medical devices

(pacemaker, cochlear implant etc.) to avoid potential

• Do not clean with harmful chemicals or detergents

www.mycomsol.com.au

iPhone is a trademark of Apple inc..