



Anti-Ligature En-Suite Door Set

Operation and Maintenance Manual



The load release en-suite doors in this unit remove all known ligature points.

- They offer privacy and dignity, enabling partial observations (head and feet check).
- In day-to-day use the leaves will rarely detach.
- The leaves detach on ligature attempt (approximately 8kg). Load release is the only safe option to prevent ligatures. Impossible to remove ligature risk with solid, permanently attached door.
- The staff-only reset (using the Lifeline Key) is optional at point of purchase. It's designed to disrupt the ligature learning process - when a service user uses multiple attempts to practice their technique.



STAFF-ONLY RESET: HOW TO ATTACH THE LEAF



STEP 1

With the leaf positioned across the doorway, offer up the leaf to the top pivot.

NOTE - the door must be in the closed [zero degrees] position when reattaching it.



STEP 2

While holding the leaf in place, insert the Lifeline key and turn it in either direction.

You'll hear an audible click when the magnet engages.



STEP 3

Align the bottom pivot with the bottom magnet



STEP 4

Test the leaf by opening to 90 degrees.



STEP 5

Make sure the nibs are attached properly by swinging the door back and forth.



Anti-Ligature En-Suite Door Set

Operation and Maintenance Manual

Maintenance and Cleaning

Cleaning the Door Leaves and Frame Pivots

- Do not use solvents, neat bleach, phenolic based cleaning solutions or abrasive products to clean the door leaves or frame pivots.
- All surfaces to be wiped down with cleaning wipes or a disposable soft cloth moistened with a mild detergent diluted in warm water. The wipe/cloth should be changed during the cleaning process if it becomes soiled.
- For the door leaves:



DO NOT
BLEACH



HAND
WASH



DO NOT
WRING

Maintenance

Door leaves and pivots should be checked for proper condition on a regular basis
Any loose parts/poor condition should be reported and parts replaced/fixed as required

ABOUT HIPAC

We are an Australian healthcare company that guarantees to stand behind all our medical products, both manufactured and imported, because we're here for the life of our products and clients.

PO Box 797, 36 Long St. Goulburn NSW 2580, Australia
P. +61 2 4823 0000 E. info@hipac.com.au

SYDNEY | MELBOURNE | BRISBANE | ADELAIDE | PERTH

hipac.com.au

ABN 27 600 353 688