

USER'S GUIDE

YP06328 (MULTI FUNCTION SPORT LCD WATCH)

-  **EL Backlight**
-  **Stopwatch**  **Countdown Timer**
-  **Dual Time**  **5 Alarms**
-  **100 Years Calendar**  **Chime**
-  **50M Water Resistant**  **Battery (CR2025)**


BUTTONS

• Button operation are indicated using the letters shown in the illustration.



- A -- Reset/Stop
- B -- Mode
- C -- EL backlight
- D -- Start / Lap
- E -- EL backlight

DISPLAY



MODE SELECTION

• Press "B" to change mode to mode in the following sequence:
Timekeeping Mode - Stopwatch Mode - Data mode - Countdown Mode - Alarm Mode - Dual Time Mode.

a TIMEKEEPING

- 12/24H Format;
- Hour, Minutes, Seconds, Day of week, Date;
- 100 years Calendar (2000~2099).



b STOPWATCH

- 1/100 second unit;
- 150 LAP;
- Measuring range: 00'00"00 ~ 9:59'59".




c DATA

- 150 LAP & SPL data.



d COUNTDOWN

- Countdown range: 23:59'59" ~ 0'00"00.



e ALARM

- 5 Alarms;
- Hourly time signal;
- The alarm sounds at the preset time each day.



f DUAL TIME

- The time for other time zone.



a TIMEKEEPING

Calendar

- In the timekeeping mode, press and hold "D" to display: Year, Month, Date.



Time Setting

1. In the timekeeping mode, press and hold "A" until the seconds to flash (flashing indicated in set mode);



2. Press "C", "D" or "E" to reset the seconds ;



3. Press "B" change to the next selection;



4. Press "D" to increase the number, press and hold to increase at high speed; Press "C" or "E" to decrease the number, press and hold to decrease at high speed;



5. Repeat step 3 and 4, the selection in the following sequence: Seconds - Hour - Minutes - Year - Month - Date - 12/24H format;



6. Press "A" to exit the set state, after you set (The day of week is automatically displayed in accordance with year, month and date setting).

b STOPWATCH

A Lap Time

1. In the stopwatch mode, press "D" to start the stopwatch;



2. Press "A" to stop the stopwatch;



3. To reset the stopwatch by pressing "A" again;



Split Time

1. In the stopwatch mode, press "D" to start the stopwatch;



2. Press "D" to display the split time, auto change to running state after 2 seconds;



3. Repeat step 2, you can measure the multi split time;



4. Press "A" to stop the stopwatch.



C DATA

LAP



1. In the data mode, the watch display the time of first LAP;



2. Press "D" to forward browse the time for another ;



3. Press "C" or "E" to backward browse the time for another ;



Split



4. In the data mode, Press "A" the watch display the time of first SPL;



5. Press "D" to forward browse the time for another ;



6. Press "C" or "E" to backward browse the time for another ;



7. Press "A" to enter the stopwatch mode in the browse split time state.



d COUNTDOWN

- When the countdown reaches zero, the alarm sounds for about 60 seconds and press any button to break it.

Countdown Time Setting

1. In the countdown mode, press and hold "A" the hour to flash (flashing indicated in set mode);



2. Press "D" to increase the hour, press and hold to increase at high speed; Press "C" or "E" to decrease the hour, press and hold to decrease at high speed;



3. Press "B" change to the next selection;



4. Press "D" to increase the number, press and hold to increase at high speed; Press "C" or "E" to decrease the number, press and hold to decrease at high speed;



5. Repeat step 3 and 4, the selection in the following sequence: Hour - Minutes - Seconds;

6. Press "A" to exit the set state, after you set.



Use Countdown Timer

1. Press "D" to start the countdown timer;



2. Press "A" to Pause the countdown timer.



e ALARM

- The alarm sounds at the preset time each day for about 60 seconds, press any button to break it.

Alarm and Chime

- In the alarm mode, press "A" to select chime, Alarm1 ~ Alarm5.



- In the chime state, press "D" to on/off the chime.



- In the Alarm1 ~ Alarm5 state, press "D" to on/off the alarm.



Alarm1 Setting

1. In the alarm mode, press and hold "A" the hour to flash, the indicator " (●) " appear (flashing indicated in set mode);



2. Press "D" to increase the hour, press and hold to increase at high speed; Press "C" or "E" to decrease the hour, press and hold to decrease at high speed;



3. Press "B" to select the minutes;



4. Press "D" to increase the minutes, press and hold to increase at high speed; Press "C" or "E" to decrease the minutes, press and hold to decrease at high speed;



5. Press "A" to exit the set state, after you set.

- Setting and operation of the Alarm1~Alarm5 are the same.

ATTENTION

- Never try to open the case or remove its back cover.
- Do not operate buttons underwater.
- Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
- Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
- Avoid exposing the watch to temperature extremes.
- Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
- Avoid to wear the watch in electromagnetic, static conditions.

f DUAL TIME

Dual Time Setting

1. In the dual time mode, press and hold "A" the hour to flash (flashing indicated in set mode);




2. Press "D" to increase the hour, press and hold to increase at high speed; Press "C" or "E" to decrease the hour, press and hold to decrease at high speed;



3. Press "B" to select the minutes;



4. Press "C", "D" or "E" to change the minutes (press once change 30 minutes);



5. Press "A" to exit the set state, after you set.

BACKLIGHT

- The backlight that uses an EL (electroluminescent) cause the display to glow for easy reading in the dark.

Use EL Backlight

- In any mode, press "C" or "E" to illuminate the display about 3 seconds.

