

# Goldair™



## Operating Instructions

### 8.8L Stainless Steel Urn



Model: GSSU120

# General Care and Safety Guide

**YOUR SAFETY IS IMPORTANT TO US. PLEASE ENSURE YOU TAKE NOTE OF THE INSTRUCTIONS AND WARNINGS OUTLINED IN THIS MANUAL.**

Always choose a safe location for the urn, keeping in mind the safety precautions outlined. Ensure all packaging has been removed from the unit before use. This appliance requires no installation.

**WARNING:** TOO LITTLE WATER MAY DAMAGE THE HEATING ELEMENT AND OVERFILLING MAY CAUSE THE BOILING WATER TO BE EJECTED.

**WARNING:** TAKE CARE WHEN MOVING THE URN AS THE WORK SURFACE MAY BE SUBJECT TO RESIDUAL HEAT AFTER USE.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Ensure that the urn is switched off from the supply mains before moving.
- Use only the voltage specified on the rating plate of the appliance.
- Keep all objects at least 1 Metre from the front, sides and rear of the appliance
- This appliance is intended for household use only and not for commercial or industrial use.
- Use this appliance only as described in this manual. Any other use is not recommended by the manufacturer and may cause fire, electric shock or injury.
- The common cause of overheating is using the appliance without the appropriate amount of water. Ensure that there is sufficient water in the urn before turning on and do not allow to boil dry.
- Always unplug appliance when not in use.
- When the appliance has been unpacked, check it for transport damage and ensure all parts have been delivered. If parts are missing or the appliance has been damaged, contact the Black & Decker Customer Services Team.
- If your appliance does not work, or is not working properly, contact the place of purchase. Repair work on the appliance by unqualified persons can cause serious risk to the user.
- Ensure hands are dry before handling the plug or the main unit.
- Carry out regular checks of the supply cord to ensure no damage is evident.
- Ensure that the cord is fully extended (not coiled) while in use.

# General Care and Safety Guide

- Avoid contact with the metal parts. Keep hands, hair, clothing, away from the outside of the urn during operation to reduce the risk of injury to person and/or damage to the unit.
- Switch off and use handles provided when moving.
- It is recommended that this urn is plugged directly into the wall socket.
- A correctly specified, undamaged extension cord may be used with this urn provided it is used in a safe manner.
- Never place appliance close to radiant heat source.
- Never operate in areas where petrol, paint or other flammable liquids are used or stored.
- Never insert or allow foreign objects to enter any opening, as this may cause an electric shock, fire or damage to the appliance.
- Never use abrasive cleaning products on this appliance. Clean with a damp cloth (not wet) rinsed in hot soapy water only. Always remove plug from the mains supply before cleaning.
- Never connect the appliance to mains supply until completely assembled and adjusted.
- Never remove plug from power socket until the appliance has been switched off.
- Never remove plug from power socket by pulling cord – always grip plug.
- Never twist, kink or wrap the cord around the appliance, as this may cause the insulation to weaken and split. Always ensure that all cord has been removed from any cord storage area and is unrolled before use.
- Never use this appliance in the immediate surrounds of a bath, a shower, or a swimming pool or other liquids. The appliance must not be immersed in any liquids.
- Due to the risk of injury, never use this appliance for any purpose other than its intended use. This appliance is intended for use in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses, by clients in hotels, motels, bed and breakfast type environments and other residential type environments
- Never use this appliance outdoors.
- Never operate the appliance with a damaged cord or plug, after it malfunctions, or if it has been damaged in any manner. Have the appliance checked and repaired by a qualified electrician if repair is necessary.
- Never place the unit in wardrobes or other enclosed spaces as this may cause fire hazards.

# Components

1. Lid
2. Water Gauge
3. Power Switch
4. Indicator Light



# Operating Your Urn

Always choose a safe location for the urn, keeping in mind the safety precautions outlined. Ensure all packaging has been removed from the unit before use. This appliance requires no installation.

**WARNING: TOO LITTLE WATER MAY DAMAGE THE HEATING ELEMENT AND OVERFILLING MAY CAUSE THE BOILING WATER TO BE EJECTED.**

**WARNING: TAKE CARE WHEN MOVING THE URN AS THE WORK SURFACE MAY BE SUBJECT TO RESIDUAL HEAT AFTER USE.**

Place the unit on a dry, level and heat-resistant surface, away from the edge of the work surface. Do not use the unit on the floor.

For first time use, it is recommended that you fill the urn to the maximum level mark with fresh tap water, then boil and empty. Repeat this process at least two times to clear the urn of any dust or materials from the manufacturing process. Do not drink this water.

1. Open lid and fill with water, ensuring you do not exceed the maximum level.
2. Ensure the switch is in the OFF position before plugging the power plug into the socket.
3. Replace the lid and switch the unit on. The BOIL indicator light will illuminate and the water will become hot, and begin to boil.
4. The BOIL indicator light will turn off once the water is boiled and the KEEP WARM indicator light will illuminate. This indicates that the urn is now preserving heat.
5. The urn will continue to switch on/off as required, to maintain the water temperature.
6. After use, please ensure you switch off and unplug the unit.

**This unit is fitted with an automatic shut-down feature, which serves as a boil-dry protection device. It will automatically shut-down once it detects no water inside the urn. If this feature has activated, press the reset button at the base of the unit to restart the appliance.**

# Cleaning

The unit must be cleaned thoroughly after each use.

To avoid risk of electric shock, before cleaning, you **MUST ALWAYS** switch off and unplug the unit.

Use only a soft, damp cloth to gently wipe the urn and dry well.

DO NOT immerse the urn in water base in water.

DO NOT use harsh chemicals to clean the urn. A mild cleaning agent can be used.



## PROOF OF PURCHASE

To receive warranty retain receipt as proof of purchase.

**Goldair™**

### SUPPORT AND TECHNICAL ADVICE

#### Goldair – New Zealand

Monday – Friday 8am-5pm  
Phone +64 (0)9 917 4000  
Phone 0800 232 633  
info@cdb.co.nz

#### Goldair – Australia

Monday – Friday 8am-5pm  
Phone +61 (0)3 9365 5100  
Phone 1300 465 324  
info@cdbgoldair.com.au



## One Year Warranty

Thank you for purchasing this Goldair product. Your product is warranted against faults and manufacture when used in normal domestic use for a period of **one years**. In non-domestic use Goldair limits the voluntary warranty to **three months**.

Goldair undertake to repair or replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period.

This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

PLEASE KEEP YOUR RECEIPT AS THIS WILL HELP VERIFY YOUR WARRANTY.

The benefits given to you by this warranty are in addition to other rights and remedies available to you under law in relation to the goods or services to which this warranty relates.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand this warranty is additional to the conditions and guarantees of the Consumers Guarantee Act (1993).

### Goldair – New Zealand

CDB Goldair  
PO Box 100-707  
N.S.M.C  
Auckland

Phone +64 (0)9 917 4000  
Phone 0800 232 633  
[www.goldair.co.nz](http://www.goldair.co.nz)

### Goldair – Australia

CDB Goldair Australia Pty  
PO Box 574  
South Morang  
Victoria, 3752

Phone +61 (0)3 9365 5100  
Phone 1300 GOLDAIR (1300 465 324)  
[www.goldair.com.au](http://www.goldair.com.au)

### Goldair Two Year Warranty (IMPORTANT: Please complete and retain this warranty card)

Name	
<hr/>	
<hr/>	
Address	
<hr/>	
<hr/>	
<hr/>	
<hr/>	
Place Of Purchase	Date Of Purchase
<hr/>	<hr/>
Name Of Product	Model Number
<hr/>	<hr/>
Attach a copy of the purchase receipt to this warranty card	

# Goldair™



CDB  Goldair™

New Zealand  
PO Box 100707,  
North Shore Mail Centre,  
Auckland, 0745  
[www.goldair.co.nz](http://www.goldair.co.nz)

Australia  
PO Box 574,  
South Morang,  
Victoria, 3752  
[www.goldair.com.au](http://www.goldair.com.au)