

JB05POC

Pocket Calculator



Manufacturer: OFFICEWORKS LTD 236-262 East Boundary Road, Bentleigh East VIC 3165, Australia

A: KEY OPERATIONS

: Power on /Clear /Clear error AC. : All clear +/- : Sign change key (Change the sign of the displayed value from positive to negative or vice versa). ▶ : Right shift key (Shifts the displayed value to the right, deleting the rightmost digit). 0 : Numeral kev X ÷ = √ % : Function key M+ : Memory plus (Adds the displayed value to the independent memory). M- : Memory minus (Subtracts the displayed value from the independent memory). MRC: Recall memory/Memory clear.

HMS: Time operation

SET : Sets the tax rate when pressing [SET] & [TAX+].

STORE

TAX+: Stores tax rate, and calculates price - plus - tax.

RECALL

TAX-: Recalls tax rate, and calculates price - less - tax.

B: LCD DISPLAY

M (MEMORY): Independent memory.

- (-MINUS) : Displayed when the value is negative.

: The display shows "ERROR" when the answer E (ERROR) exceeds the maximum number of display.

1. Press AC to clear all values.

2. Press the key to clear the "ERROR" whilst keeping the value on display. MRC are stored.

C: HOW TO CHANGE THE BATTERY

- * This product utilises two power sources:
 - Solar energy
 - ② LR54 alkaline button battery (1.5V)



- * Opening the battery compartment by using cross screwdriver.
- * Auto power-off: After approximately 5-12 minutes.
- * When the display becomes blurry, this indicates the calculator is low on battery. Recharge by leaving it in a bright location but out of direct sunlight, or replace the battery.

D: CALCULATION EXAMPLES

Example	Operation	Display
25 x 5 -) 84 ÷ 3 +) 68+17 182	AC 25 × 5 M+ 84 ÷ 3 M- 68 + 17 M+ MRC	M 125. M 28. M 85. M 182. 182.
123478 + 5	123456	123 456. 1 234. 123 478. 123 483.
456 + 378	456 + 375 a 378 =	0. 834.
32 x 5 +4 - 6 79 ÷ 2-30+88 175+3	AC 32 × 5 + 4 - 6 = 79 ÷ 2 - 30 + 88 = 175 + 3 =	0. 158. 97.5 178.
$100+50-30 = (-10)x20 \div 0.5 =$	100 + 50 - 30 = 10 + 20 ÷ 0.5 =	0. 120. = -400.
1234567890 x 66666=	1234567890 × 66666 = @	× 1234567890 E82.3037029547 82.3037029547 0.

Example	Operation	Display	
√9 X 5	9 ✓ × 5 =	15.	
• 10% of 1500 • (1500's 10%=) 5% add-on of 1500 (1500+5%=) (1500-5%=) • percentage of 20 against 500	1500 × 10 % 1500 + 5 % 1500 - 5 % 20 ÷ 500 %	150. 1'575. 1'425. 4.	
Setting Rate 8%	AC 8 SET store TAX+	0. (flash)TAX% 8. TAX% 8.	
Checking rate	AC SET TAX-	TAX% 8.	
At what price and amount of tax one must sell to include 8% tax rate when cost is 1000.	AC STORE 1000 TAX+	0. TAX+ 1080. TAX 80.	
At what price and amount of tax one must sell to exclude 8% tax rate when cost is 1000.	1000 TECAL. TAX- TAX-	TAX- 925.92592593 TAX 74.074074074	

Example	Operation	Display	
According to 12 hours, 34 minutes and 56 seconds equivalent decimal	AC 12 [HMS] 34 [HMS] 56 [HMS] [HMS]		12-34'56" 12.5822222222 12-34'56"
Transform 72 seconds to minutes	AC 0 HMS HMS 72		0-00'72" 0-01'12"
Will be 350 minutes transform for hours	AC 350 ÷ 60 ≡		5.83333333333 5-50'00"
Calculated under the condition of \$9 per hour worked 7.5 hours	7 HMS 30 HMS HMS = HMS	×	9 7-30'00" = 67.5

★ If the display is malfunctioning, please use a sharp tool, such as a pin or toothoick, to activate the RESET button to restart the calculator.

The RESET button is located at the back of the calculator.

Power Supply

This calculator is powered by one LR54 1.5V alkaline button battery.



♠ WARNING!

- WARNING! KEEP BATTERIES OUT OF REACH OF CHILDREN.
- · Never allow children to replace button batteries on any device.
- Swallowing or placing inside any part of the body may lead to severe or fatal injuries in as little as 2 hours or less due to chemical burns and potential perforation of the oesophagus.
- If you suspect your child has swallowed a button battery or placed inside any part of the body immediately call the 24-hour POISONS INFORMATION CENTRE on 13 11 26
- for prompt advice. If your child is having any difficulty breathing, contact 000.

 Examine devices and make sure the battery compartment is correctly secured, e.g. that the
- Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened. Do not use if compartment is not secure.
- Dispose of used button/coin batteries immediately and safely. A battery can still be dangerous even when it can no longer operate the device. Place sticky tape around both sides of the battery and dispose of it immediately out of reach of children in an outside bin
- or recycle safely.

 Tell others about the risk associated with button batteries and how to keep their children safe.