

KAMBROOK

THE SMARTER CHOICE



8 Litre
Urn
KUR10

Instruction Booklet

Important

Please retain your instruction book for future use.

In the event that you need some assistance with your Kambrook appliance, please contact our Customer Service Department on 1300 139 798 (Australia) or 09 271 3980 (New Zealand). Alternatively, visit us on our website at www.kambrook.com.au

Contents

| | |
|--|-----|
| Kambrook Recommends Safety First | p4 |
| Your Kambrook 8 Litre Urn | p6 |
| Operating Your Kambrook 8 Litre Urn | p7 |
| Care and Cleaning | p9 |
| Warranty | p12 |

IMPORTANT: Please retain your instruction book for future use.

At Kambrook, we believe that safe performance is the first priority in any consumer product, so that you, our valued customer can confidently use and trust our products. We ask that any electrical appliance that you use be operated in a sensible fashion with due care and attention placed on the following important operating instructions.

Important Safeguards For Your Kambrook 8 Litre Urn

- Carefully read all instructions before operating and save for future reference.
- Remove any promotional stickers before using the urn for the first time.
- This appliance is designed for the boiling of drinking quality water only, never use it to heat or boil any other liquids or food.
- This appliance is for household use only. Do not use this appliance for other than its intended use. Do not use outdoors.
- Unwind the cord before use.
- Do not leave the appliance unattended when in use.
- Do not touch hot surfaces. Use handles for lifting and carrying the appliance.
- Always use the appliance on a dry, level surface. The urn is not intended for use on water craft or other non-stationary vehicles.
- Do not operate the urn on an inclined surface.
- Do not move the urn while it is switched on.
- Keep clear of walls, curtains and other heat or steam sensitive materials. Minimum 200mm distance.
- Do not place the urn on or near a hot gas or electric burner, or where it could touch a heated oven.
- Do not let the cord hang over the edge of a table or counter, touch hot surfaces or become knotted.
- Do not immerse urn cord or power plug in water or any other liquid.
- Always switch appliance to 'STAND BY', switch off at the power outlet and then remove the plug from the power outlet before attempting to move the appliance, when the appliance is not in use and before cleaning or storing.

Important Safeguards For All Electrical Appliances

- Fully unwind the power cord before use.
- Do not let the power cord hang over the edge of a bench or table, touch hot surfaces or become knotted.
- To protect against electric shock do not immerse the power cord, power plug or motor base in water or any other liquid.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- It is recommended to regularly inspect the appliance. To avoid a hazard do not use the appliance if power cord, power plug or appliance becomes damaged in any way. Return the entire appliance to the nearest authorised Kambrook Service Centre for examination and/or repair.
- Any maintenance other than cleaning should be performed at an authorised Kambrook Service Centre.
- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. Misuse may cause injury.
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.

Your Kambrook 8 Litre Urn

1. Safety locking lid
2. Cool touch carry handles
3. Water window
4. 'POWER' on light
5. Variable temperature control
6. Non-drip tap with two way flow lever

Not Shown

- 1800 watt concealed element
- Boil dry cut out protection
- Safety reset button (under the base)



Operating Your Kambrook 8 Litre Urn

Before First Use

Remove any promotional and packaging materials.

It is recommended that before the first use, the urn is filled to the maximum level, boiled and water discarded.

1. Fully unwind power cord.
2. Place the urn on a dry, level surface.
3. To fill with water, turn the locking lid anti-clockwise and remove. Use a small container to fill the urn. Do not fill above the maximum 8 litre mark on the external water window as boiling water may splash out from the urn. (Fig. 1)



Fig. 1

4. After filling the urn, ensure that the lid is replaced and locked firmly into position.
5. Plug the power cord into a 230V or 240V power point and switch on.
6. Turn the variable heat control to '5' for fast boiling. The red 'POWER' on light will illuminate.

When the unit has boiled, select the desired setting from 'MIN' to '4' to maintain temperature (Kambrook recommends setting '2' or '3' for tea or coffee).

To pour hot water, place a cup below the non-drip tap and push the tap down. For continuous pouring, lift the tap in the vertical position.

After use and before cleaning, switch the appliance to 'STAND BY', switch the power off at the power point and then remove the plug.

NOTE: The lid should always be fitted and locked into position when in use.

Use caution when pouring water from the urn, as boiling water will scald. Do not pour the water too quickly.

Do not open the lid when in operation as steam may escape from the top.

Steam may escape from the steam holes on top of the urn. Exercise caution at all times.

When the urn is in use, please do not place the urn under any objects such as a cupboard, as the escaped steam may cause damage to the overhead object due to heating or water condensation.

Always empty the urn before moving to a new position/location.

Never carry the urn when in operation.

Always use the handles to carry the urn.

Operating Your Kambrook 8 Litre Urn continued

Safety Boil Dry Protection

The urn is fitted with a safety device which protects against overheating should the appliance be operated with insufficient water or has boiled dry. If this occurs, the urn will stop heating. The red 'POWER' on light will turn off.

Switch the appliance to 'STAND BY', switch the power off at the power point and allow the urn to cool.

Press the safety reset button under the base before refilling the urn. The safety device will then be reset and the urn will be ready for use.

Care and Cleaning

Always switch the appliance to 'STAND BY', switch the power off at the power point and then remove the plug before cleaning. Never immerse the urn controls or cord in water, or allow moisture to come in contact with these parts.

Removal of Mineral Deposits

Mineral deposits in tap water may cause the urn element plate to discolour. This may be removed by using a commercial kettle descaler which is available from most leading supermarkets, department and hardware stores. Alternatively;

1. Fill the urn until $\frac{2}{3}$ full with 1 part vinegar and 2 parts water. Boil and allow to stand overnight.
2. Empty the solution from the urn. Fill the urn with clean water, bring to boil and discard the water. Repeat and the urn will be ready for use.

To Clean the Exterior

The outside of the urn may be wiped over with a damp cloth and polished with a soft, dry cloth.

NOTE: Do not use chemical, steel wool, or abrasive cleaners to clean the urn.

Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Kambrook 12 Month Replacement Warranty

In Australia, this Kambrook Replacement Warranty does not affect the mandatory statutory rights implied under the Trade Practices Act 1974 and other similar State and Territory legislation relating to the appliance. It applies in addition to the conditions and warranties implied by that legislation.

In New Zealand, this Kambrook Replacement Warranty does not affect your mandatory statutory rights implied under the Consumer Guarantees Act 1993 in relation to the appliance. It applies in addition to the conditions and guarantees implied by that legislation.

This Kambrook Replacement Warranty is valid only in the country of purchase, but other statutory warranties may still apply.

This Warranty card and the purchase receipt for this product are to be retained as proof of purchase and must be presented if making a claim under the Kambrook Replacement Warranty. Please note that under any applicable statutory warranty you are not required to produce these documents, but may be required to provide a proof of purchase.

Kambrook warrants the purchaser against defects in workmanship and material for a period of 12 months domestic use from the date of purchase (or 3 months commercial use).

The Kambrook Replacement Warranty does not apply to any defect, deterioration, loss, injury or damage occasioned by, or as a result of, misuse or abuse, negligent handling or if the product has been used other than in accordance with the instructions. The Kambrook Replacement Warranty excludes breakables such as glass and ceramic items, consumable items and normal wear and tear.

This Kambrook Replacement Warranty is void if there is evidence of the product being tampered with by unauthorised persons.

If the product includes one or a number of accessories only the defective accessory or product will be replaced. Subject to your statutory rights, in the event of Kambrook choosing to replace the appliance, the Kambrook Replacement Warranty will expire at the original date, i.e. 12 months from the original date of purchase.

In the event that you need some assistance with your Kambrook appliance, please contact our Customer Service Department on 1300 139 798 (Australia) or 09 271 3980 (New Zealand). Alternatively, visit us on the website at www.kambrook.com.au

Kambrook 12 Month Replacement Warranty

Your Purchase Record (Please Complete)

Attach a copy of the purchase receipt here.

Date Of Purchase _____

Model Number _____

Serial Number _____

Purchased From _____

(Please don't return purchase record until you are making a claim)

Register your warranty at www.kambrook.com.au/service.asp

Kambrook - Australia
Building 2, Port Air Industrial Estate
1A Hale Street
Botany NSW 2019
Australia
Customer Service Line 1300 139 798
Customer Service Fax 1800 621 337

Kambrook - New Zealand
Private Bag 94411
Botany, Manukau
Auckland 2141
New Zealand
Customer Service Line/Spare Parts
0800 273 845 or 09 271 3980
Customer Service Fax 0800 288 513

KAMBROOK
THE SMARTER CHOICE

Due to continual improvement in design or otherwise, the product you purchase may differ slightly from the illustration in this book. Issue A10