

SMITH

DESIGNED BY METRICA

ASSEMBLY INSTRUCTION



SMITH TABLE WITH WOODEN TOP

PACKAGING

- CARDBOARD BOX WITH POLYSTYRENE ON ALL SIDES: SET OF TABLE LEGS WITH FELT PADS ALREADY ATTACHED
 - CARDBOARD BOX WITH POLYSTYRENE ON ALL SIDES: METAL FRAME WITH WOODEN SIDES AND TOP ALREADY ATTACHED, BAG WITH 8 SCREWS TO FIX METAL L OF THE WOODEN LEGS ONTO THE STRUCTURE AND 6 SCREWS WITH WASHER TO FIX SET OF LEGS TO FRAME AND A LONG ALLEN KEY
-

IMPORTANT NOTE

- ENSURE THAT ALL STEPS ARE FOLLOWED IN THE CORRECT ORDER AND THAT NO STEP IS LEFT OUT.
 - A MINIMUM OF TWO PEOPLE ARE REQUIRED FOR ASSEMBLY.
 - TO PREVENT ANY DAMAGE TO THE PRODUCT, DO NOT USE A CUTTER KNIFE/ SHARP OBJECT TO OPEN THE BOXES.
-

ASSEMBLY INSTRUCTIONS

1. REMOVE THE FRAME AND THE LEGS FROM THE PACKAGING
2. PLACE THE FRAME WITH THE ALREADY ASSEMBLED TOP UPSIDE DOWN ONTO THE FLOOR
3. UNSCREW THE TOP COMPLETELY AND SET ASIDE (THE TOP WILL BE REASSEMBLED AT THE END)
4. LOOSEN ALL THE SCREWS WHICH FIX THE WOODEN SIDES ONTO THE METAL FRAME
5. ON A BLANKET, TILT THE METAL FRAME WITH THE LOOSENED WOODEN SIDES ONTO THE SIDE AND PLACE ONE SET OF THE LEGS INTO POSITION; ENSURE THAT THE METAL L SITS CORRECTLY IN ITS POSITION
6. FIX ONLY THE 3 SCREWS WITH WASHER WHICH CONNECT THE WOODEN LEGS TO THE ENDS OF THE METAL FRAME
7. REPEAT STEP 5 AND 6 ON THE OTHER END
8. CHECK AND TIGHTEN THE SCREWS CONNECTING THE WOODEN LEGS TO THE ENDS OF THE METAL FRAME
9. NOW INSERT THE SCREWS FIXING THE METAL L ONTO THE WOODEN SIDES AND TIGHTEN
10. TIGHTEN THE SCREWS WHICH FIX THE WOODEN SIDES ONTO THE METAL FRAME
11. MAKE SURE THAT ALL SCREWS ARE TIGHTENED
12. LAY THE TABLE TOP ON A BLANKET WITH THE UNDERSIDE FACING UP
13. PLACE THE ASSEMBLED TABLE STRUCTURE ONTO THE WOODEN TOP AND REASSEMBLE THE TOP WITH ALL SCREWS
14. PLACE THE TABLE ON ITS LEGS, MAKING SURE THAT IT IS STABLE
15. IF THE TABLE STRUCTURE IS MOVING TOO MUCH, RE-CHECK THAT ALL SCREWS ARE TIGHTENED CORRECTLY

SMITH TABLE WITH GLASS TOP

PACKAGING

- CARDBOARD BOX WITH POLYSTYRENE ON ALL SIDES: SET OF TABLE LEGS WITH FELT PADS ALREADY ATTACHED
 - CARDBOARD BOX WITH POLYSTYRENE ON ALL SIDES: METAL FRAME WITH WOODEN SIDES ALREADY ATTACHED, BAG WITH 8 SCREWS TO FIX THE METAL L OF THE WOODEN LEGS ONTO THE STRUCTURE AND 6 SCREWS WITH WASHER TO FIX SET OF LEGS TO FRAME AND A LONG ALLEN KEY
 - WOODEN CRATE WITH POLYSTYRENE ON ALL SIDES: GLASS TOP AND 14+2 OVAL RUBBER PADS
-

IMPORTANT NOTE

- ENSURE THAT ALL STEPS ARE FOLLOWED IN THE CORRECT ORDER AND THAT NO STEP IS LEFT OUT.
 - A MINIMUM OF TWO PEOPLE ARE REQUIRED FOR ASSEMBLY.
 - TO PREVENT ANY DAMAGE TO THE PRODUCT, DO NOT USE A CUTTER KNIFE/ SHARP OBJECT TO OPEN THE BOXES.
-

ASSEMBLY INSTRUCTIONS

1. REMOVE THE FRAME AND THE LEGS FROM THE PACKAGING
 2. PLACE THE FRAME UPSIDE DOWN ONTO THE FLOOR AND LOOSEN THE SCREWS WHICH FIX THE WOODEN SIDES ONTO THE METAL FRAME
 3. ON A BLANKET, TILT THE METAL FRAME WITH THE LOOSENED WOODEN SIDES ONTO THE SIDE AND PLACE ONE SET OF THE LEGS INTO POSITION; ENSURE THAT THE METAL L SITS CORRECTLY IN ITS POSITION
 4. FIX ONLY THE 3 SCREWS WITH THE WASHER WHICH CONNECT THE WOODEN LEGS TO THE ENDS OF THE METAL FRAME
 5. REPEAT STEP 3 AND 4 ON THE OTHER SIDE
 6. CHECK AND TIGHTEN THE SCREWS CONNECTING THE WOODEN LEGS TO THE ENDS OF THE METAL FRAME
 7. NOW INSERT THE SCREWS FIXING THE METAL L ONTO THE WOODEN SIDES AND TIGHTEN
 8. TIGHTEN THE SCREWS WHICH FIX THE WOODEN SIDES ONTO THE METAL FRAME
 9. MAKE SURE THAT ALL SCREWS ARE TIGHTENED
 10. PLACE THE TABLE ON ITS LEGS, MAKING SURE THAT IT IS STABLE
 11. IF THE TABLE STRUCTURE IS MOVING TOO MUCH, RE-CHECK THAT ALL SCREWS ARE TIGHTENED CORRECTLY
 12. PLACE THE GLASS TOP IN ITS WOODEN CRATE ON THE FLOOR AND REMOVE IT FROM ITS PACKAGING
 13. INSIDE THE PACKAGING/ATTACHED TO THE GLASS TOP ARE RUBBER PADS AND A DRAWING
 14. PLACE THE RUBBER PADS AS SHOWN IN THE DRAWING
 15. PLACE THE GLASS TOP ONTO THE STRUCTURE
 16. THE TOP SHOULD HAVE A CONSISTENT 2MM SHADOW EDGE ON ALL SIDES
-