




ASSEMBLY INSTRUCTIONS

6 CUBE BOOKCASE WHITE SM6CUBEWE



WARNING!

IT IS STRONGLY RECOMMENDED THAT THIS PRODUCT IS PERMANENTLY FIXED TO A WALL USING THE PROVIDED ANCHOR KIT.

This design and instruction booklet is subject to copyright.
www.officeworks.com.au

1 Carton

For spare parts or hardware call 1300 OFFICE(1300 633 423)

Estimated Assembly Time: 45minutes

Customer Service Contact Details



Spare Parts & Hardware

1300 OFFICE(1300 633 423)


People Required



General Advice




Tools Required



CAUTION: Do not use tools other than those required, as this can damage your new item.

Tools Required

To secure the unit to a wall you need following tools:



NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact 1300 OFFICE(1300 633 423).
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION

- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all screws are firmly secured.
- Check that all screws are securely tightened at least every 4 months.






WARNING

- If parts are missing, broken, damaged or worn, stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.

DANGER






- CHILDREN MUST BE SUPERVISED.

Parts List

①  2pcs	②  2pcs	③  1pc
④  4pcs	⑤  3pcs	



Hardware List

Hardware Spare Part number


A  ø5x40mm 12pcs	B  ø6x50mm 4pcs	C  ø6x30mm 20pcs	D  1pc
E  24pcs	F  ø20 12pcs	G  ø3.5x18mm 1pc	H  1pc
I  ø6x30mm 1pc	J  ø4x40mm 1pc		

Assembly



Step 1





Step 2





Step 3





Step 4



Step 5



Step 6



Step 7

Diagram illustrating Step 7 of the assembly process. The diagram shows a 3x3 grid of squares. The top square is labeled '5' and the bottom square is labeled '1'. Arrows labeled 'Push' indicate the direction of assembly. A circular inset shows a close-up of a square labeled 'E' being pushed into a hole in the top square. A legend on the left shows 'E' as a pin (24 pcs) and 'F' as a washer (12 pcs).

Step 8

G 1pc
H 1pc
I 1pc
J 1pc

WALL


1

1: WALL
2: WALL
3: WALL
4: WALL
5: WALL


The diagram illustrates the final assembly step of attaching a shelf unit to a wall. A parts list at the top identifies four components: G (a screw), H (an L-bracket), I (a long pin), and J (a short screw), each required in one piece. The main illustration shows a three-shelf unit being positioned against a vertical wall. A circular callout provides a detailed view of the corner attachment process. This callout shows the L-bracket H being secured to the wall with two screws G. Simultaneously, the long pin I is inserted through the bracket into the wall, and the short screw J is used to secure the bracket from the opposite side. Five numbered steps (1-5) describe the sequence: 1. Positioning the unit; 2. Inserting the pin I; 3. Driving the pin I into the wall with a hammer; 4. Tightening the screw G; 5. Tightening the screw J. A large number '1' in a circle indicates this is the first step of this specific phase.

A red circular prohibition sign with a diagonal slash. Inside the circle is a black silhouette of a person pushing a heavy, tilted rectangular load. This sign is placed over the 'Pushing or pulling heavy loads' entry in the table.

MAXIMUM WEIGHT CAPACITY



NOTE: 15kg maximum
weight capacity per shelf



NOTE: 15kg maximum
weight capacity per shelf

 **CAUTION:** This product is intended to hold the maximum weight indicated.
Exceeding the maximum weight will result in instability and may cause injury.

Warranty 3 years

Product Warranty – valid for Australian customers only

Officeworks Ltd warrants that this product will be free from defects and work as intended for 3 years from the date of purchase by the original customer.

If the product has any defects or does not work as intended during the Warranty Period, Officeworks will, at its election and at its expense, repair or replace the product.

This warranty does not apply:

- To cosmetic damage;
- To damage caused by consumables used in connection with the product (such as cleaning products);
- Where the product has not been used in accordance with all provided instructions;
- To damage arising from fair wear and tear;
- Where the product has not been subject to reasonable use;
- Where the product has been intentionally or negligently damaged; and/or if the customer has attempted to repair the product.

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

This warranty is provided in addition to any rights you may be entitled to under the Competitions & Consumer Act 2010.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Thank you for your purchase. Please retain your receipt to validate warranty.

If you would like to know more about our furniture products, please visit www.officeworks.com.au