

4 Port USB Charging Station with USB-C PD **DCS448**



User Manual

Product Features

Ideal for iPhone, iPad, MacBook, smartphone, tablet, wearables, e-Reader, camera or Bluetooth devices

Compatible with most smartphones & tablets including


- Apple Samsung Huawei Sony Google LG Oppo HTC
- Moto Nokia OnePlus Telstra & more
- 3 x USB-A 2.4A ports for charging your iPhone, iPad, smartphone, tablet or other USB devices
- 1 x high output 30W USB-C PD port to charge a MacBook or other USB-C charging laptop
- . USB-C PD (Power Delivery) ensures fast, safe & optimal charging performance
- Smart Power Chip identifies your device and provides maximum power for speedy charging times
- USB-C PD port can fast charge an iPhone Xs / Xs Max / XR X / 8 / 8 Plus from 0 to 50% in 30 minutes
- Full safety protection provides peace of mind for you and your devices
- . Built-in over charging & over current protection
- Built-in surge & short circuit protection

' When used in conjunction with a certified USB-C to Lightning Cable

Product Specifications

- Model: DCS448
- Input: DC 20V 2.4A (48W Max)
- Output USB-C PD: DC 5V 3A / 9V 3A / 12V 2A / 15V 2A / 20V 1.5A
- Output USB-A: 3 x DC 5V 2.4A (Max)
- Total Output: 48W
- Dimensions: 120mm (W) x 120mm (D) x 55mm (H)

Product Diagram



Operating Instructions

Connect the Comsol 4 port USB charging station to a power socket using the provided AC power adapter.

Turn on the power switch and the power LED will be on.

Connect your devices to any of the USB ports as required.

The USB-C PD (Power Delivery) port can provide up to 30W of power to charge a MacBook or other USB-C laptop or device.

Each USB-A port will supply up to 2.4A (12W) for fast charging of phones and tablets.

If the USB-C port is charging a MacBook or USB-C laptop, the built-in Smart Power Chip will intelligently distribute the available power across all ports.



Caution

- · Do not apply external force on any connected cable
- . Do not unplug by pulling the cable
- . Do not place the power cable or device near heating elements
- . Do not bend the pins of the power cable
- · If there are any strange sounds, smoke or ordour, disconnect the power cable immediately
- . Do not disassemble (it may cause fire or electric shock)
- . Do not put any sharp objects into the venting holes of the product (it may cause fire or electric shock)
- . Ensure to plug the cable firmly into the socket
- Do not use any cable that is damaged (it may cause fire or electric shock)
- . Do not operate the product on a bed, sofa or inside a closed space that has no ventilation
- . If dirty, wipe the product with a soft dry cloth (do not use water as it may cause electric shock)
- . Keep the power plug clean (dirt may cause a short circuit or fire)
- . Keep the product out of reach of small children
- . Don't unplug the power cable with wet hands (it may cause electric
- . If you do not intend to use the product for an extended period of time, unplug the power cable from the wall socket to avoid any chance of over heating or unwanted damage

