

Dual Port Power Bank Charger 15 000mAh

User Manual



Suitable for

- iPhone/iPad/iPod
- Most smartphones & tablets including Samsung, HTC, Motorola, Nokia, LG, Sonv. BlackBerry, Huawei, Asus, Telstra, Doro & more
- GPS devices, digital cameras, portable hand-held gaming consoles
- Portable Bluetooth devices such as fitness tracker or headset
- · eReaders such as Kindle, Kobo & Sonv

Features

- Unique soft touch material
- Dual USB ports for simultaneous charging of two devices
- 2.1A high output for fast charging of iPad
- · Rechargeable more than 800 times
- Four LED indicators to show remaining capacity
- · Includes micro USB cable for charging and re-charging
- Built-in over charging and short circuit protection Input: DC5V 2A
- Output 1: DC5V 1A
- Output 2: DC5V 2.1A
- . Charging Time: 8 to 9 hours
- Size: 138mm (L) x 78mm (W) x 24mm (H)
- Weight: 343g

To Charge Power Bank

Charge via USB Wall Charger







- Using the included USB cable, connect the larger USB connector to an AC wall adapter or USB port on a computer
- Connect the smaller micro USB connector to the input port on the power hank
- During charging the LEDs will flash to show charging status.
- When charging is complete all four LED's will be permanently on.

To Charge Phone or USB Device



- USB 1 Output is for charging a phone or other USB device
- USB 2 Output is for fast charging an iPad or tablet
- USB 2 Output can also be used to charge a phone or any other USB device
- Using your phone, tablet or other USB device's charging cable, connect
- the USB Type A connector to USB Output 1 or 2 on the power bank . Connect the other end of the cable to your device
- Charging should start automatically. If it doesn't, press the on/off button
- If your phone or device uses a standard micro USB Type B connector.
- then you can also use the included cable to charge your device When your phone or device is fully charged, the power bank will stop charging to prevent over charging or over heating

To Check Remaining Capacity

- Press the On/Off button and the LEDs will light to show remaining capacity
- . The LEDs will turn of automatically after about 20 seconds

LED ● On / ○ Off / ● Flashing	Remaining Capacity
●○○○	Less than 5%
●000	5% to 25%
••00	25% to 50%
	50% to 75%
••••	75% to 100

Important Safety Instructions

- . To maximize battery life span, fully charge power bank before first use for 8 to 9 hours
- . Store power bank in a cool and dry place.
- . Do not store power bank in hot or humid environment
- Operating temperature should be between -10c to 45c.
- If power bank is not used for long periods of time, you should charge and discharge once every three months When charging a device, the power bank may feel warm, this is a normal.
- operating condition and should not be cause for concern
- In normal conditions, the battery performance will decline over several years
- Do not dispose of power bank in heat or fire
- Do not clean power bank with harmful chemicals or detergents
- Misuse, dropping or excessive force may cause product damage

All rights reserved. Any information printed here is subject to change without notice. iPhone and iPod are trademarks of Apple Inc., registered in the U.S. and other

iPad is a trademark of Apple Inc. All other brand names, trademarks, registered trademarks and copyrights are the property of their respective owners. Comsol and the Comsol logo are trademarks of Comsol Ptv Ltd

www.comsol.com.au







