

J.BURROWS


.....


ASSEMBLY INSTRUCTIONS

SHELVING


3 SHELF UNIT

JB3TRBLSR






Tools Required




Hardware List

PARTS INVENTORY CHECKLIST	
(1) - Short Shelf Supports	QTY 6
(2) - Long Shelf Supports	QTY 6
(3) - Leg Angle Sections	QTY 4
(4) - MDF shelves	QTY 3
(5) - Plastic Floor Protectors	QTY 8




1

Decide on the position you require the bottom shelf to be.
Fit one short shelf support (1) between two leg angles (3).
Repeat this again making sure both short shelf supports (1) are at the same height.
Now fit two long shelf supports (2) matching the same height as the two short shelf supports (1).
Always hammer gently, being sure the shelf support tabs are in line with the leg angle slots.
If the tabs are out of line, simply bend them to line up either way to suit. **Do not use force** and damage the tabs.
When hammering the shelf supports, always hammer close to the leg angle.




2

Fit two more short shelf supports (1) at the desired height then fit two more long shelf supports (2) to match the short shelf supports (1).
Repeat this step for the bench supports at the top of the legs.




3

Secure the MDF shelves (4) onto the shelf supports after full frame assembly.



4

Fit the floor protectors (5) provided on the top and bottom of each leg.



For damaged or missing parts, please email products@geelongsales.com.au