







Pago Pinnacle Chair Assembly instructions

Need Help!
Assembly Videos on
[www. pagointernational. com. au](http://www.pagointernational.com.au)
E:[sales@pagointernational. com. au](mailto:sales@pagointernational.com.au)



Care instructions

Soft fabrics

Regular vacuuming is recommended. Spot clean with upholstery shampoo or dry powdered cleaner only. Test on concealed area before proceeding. Brush velvets in direction of pile with soft brush. Do not saturate fabric.

Vinyl Surfaces

Regularly vacuum away dust and grit. Do not use detergents, solvents or abrasive cleaners. To clean, use a warm, damp cloth with mild soap, then wipe dry. Should this be ineffective, seek professional advice.

Castors

Hard tyred castors are not suitable for usage on hard floors or firm chairmats in which case soft-tyred castors should be used. Soft-tyred castors can be distinguished by the tyre being a different colour to the body of the castors.

The foam and mesh on this chair comply with the ignitability/flammability requirements of AS/NZS 088.1

Pago International Pty Ltd

ABN: 40 613 903 816



Warranty 15 years

Product Warranty – valid for Australian customers only

Pago International Pty Ltd warrants that this product will be free from defects and work as intended for 15 years from the date of purchase by the original customer.

If the product has any defects or does not work as intended during the Warranty Period, Pago International Pty Ltd will, at its election and at its expense, repair or replace the product.

This warranty does not apply:

- to cosmetic damage.
- to damage caused by consumables used in connection with the product (such as cleaning products).
- where the product has not been used in accordance with all provided instructions.
- to damage arising from fair wear and tear.
- where the product has not been subject to reasonable use.
- where the product has been intentionally or negligently damaged; and/or
- if the customer has attempted to repair the product.

To make a claim under this warranty, please return your product with your receipt or proof of purchase to your nearest Officeworks store or contact 1300 633 423.

This warranty is provided in addition to any rights you may be entitled to under the Competitions & Consumer Act 2010.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.